SBI00-NRM

System Board User's Manual

A-169-M-2008

Copyright

This publication contains information that is protected by copyright. No part of it may be reproduced in any form or by any means or used to make any transformation/adaptation without the prior written permission from the copyright holders.

This publication is provided for informational purposes only. The manufacturer makes no representations or warranties with respect to the contents or use of this manual and specifically disclaims any express or implied warranties of merchantability or fitness for any particular purpose. The user will assume the entire risk of the use or the results of the use of this document. Further, the manufacturer reserves the right to revise this publication and make changes to its contents at any time, without obligation to notify any person or entity of such revisions or changes.

Changes after the publication's first release will be based on the product's revision. The website will always provide the most updated information.

© 2014. All Rights Reserved.

Trademarks

All trademarks and registered trademarks of products appearing in this manual are the properties of their respective holders.

FCC and DOC Statement on Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

Notice:

- 1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- 2. Shielded interface cables must be used in order to comply with the emission limits.

Table of Contents

Copyright2
Trademarks2
FCC and DOC Statement on Class B3
About this Manual6
Warranty6
Static Electricity Precautions
Safety Measures
About the Package8
Before Using the System Board8
Chapter I - Introduction9
9 Specifications
Chapter 2 - Hardware Installation 15
System Board Layout15System Memory16Installing the DIM Module18CPU20Installing the CPU21Installing the Fan and Heat Sink25Jumper Settings27Clear CMOS Data27PS/2 Power Select28USB Power Select29Power-on Select30COM1/COM2 RS232/RS422/RS485 Select31COM1/COM2 RS232/Power Select32
Rear Panel I/O Ports33PS/2 Mouse and PS/2 Keyboard Ports34COM (Serial) Ports35VGA Port36DVI-I Port37RJ45 LAN Ports38USB Ports39Audio41

I/O Connectors	42
S/PDIF Connector	42
Digital I/O Connectors	43
SATA (Serial ATA) Connectors	44
Cooling Fan Connectors	45
Chassis Instrusion Connector	46
Power Connectors	47
Standby Power LED	48
Front Panel Connectors	49
Expansion Slots	50
Battery	
,	
Charter 2 BIOS Setur	50
Chapter 3 - BIOS Setup	
Overview	
AMI BIOS Setup Utility	54
Main	54
Advanced	55
Chipset	70
Boot	76
Security	
Save & Exit	80
Updating the BIOS	81
Notice: BIOS SPI ROM	82
Chapter 4 - Supported Software	83
Chapter 4 - Supported Software	
	107
Chapter 5 - MAID	107
	107
RAID Levels	10/
Settings	108
Chapter 6 - Intel AMT Settings	113
Overview	113
	114
Enable Intel [®] AMT in the Intel [®] Management Engine BIOS	
Extension (MEBX) Screen	116
Appendix A - NLITE and AHCI Installation Guide	141
Appendix B - Watchdog Sample Code	153
The second	
Appendix C System Error Message	1 🗆 4
Abbendix C - System Error Message	154
As a set the D. The set to be set	

About this Manual

This manual can be downloaded from the website, or acquired as an electronic file included in the optional CD/DVD. The manual is subject to change and update without notice, and may be based on editions that do not resemble your actual products. Please visit our website or contact our sales representatives for the latest editions.

Warranty

- 1. Warranty does not cover damages or failures that arised from misuse of the product, inability to use the product, unauthorized replacement or alteration of components and product specifications.
- 2. The warranty is void if the product has been subjected to physical abuse, improper installation, modification, accidents or unauthorized repair of the product.
- 3. Unless otherwise instructed in this user's manual, the user may not, under any circumstances, attempt to perform service, adjustments or repairs on the product, whether in or out of warranty. It must be returned to the purchase point, factory or authorized service agency for all such work.
- 4. We will not be liable for any indirect, special, incidental or consequencial damages to the product that has been modified or altered.

Static Electricity Precautions

It is quite easy to inadvertently damage your PC, system board, components or devices even before installing them in your system unit. Static electrical discharge can damage computer components without causing any signs of physical damage. You must take extra care in handling them to ensure against electrostatic build-up.

- 1. To prevent electrostatic build-up, leave the system board in its anti-static bag until you are ready to install it.
- 2. Wear an antistatic wrist strap.
- 3. Do all preparation work on a static-free surface.
- 4. Hold the device only by its edges. Be careful not to touch any of the components, contacts or connections.
- 5. Avoid touching the pins or contacts on all modules and connectors. Hold modules or connectors by their ends.



Important:

Electrostatic discharge (ESD) can damage your processor, disk drive and other components. Perform the upgrade instruction procedures described at an ESD workstation only. If such a station is not available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the system chassis. If a wrist strap is unavailable, establish and maintain contact with the system chassis throughout any procedures requiring ESD protection.

Safety Measures

To avoid damage to the system:

• Use the correct AC input voltage range.

To reduce the risk of electric shock:

• Unplug the power cord before removing the system chassis cover for installation or servicing. After installation or servicing, cover the system chassis before plugging the power cord.

Battery:

- Danger of explosion if battery incorrectly replaced.
- Replace only with the same or equivalent type recommend by the manufacturer.
- Dispose of used batteries according to local ordinance.

About the Package

The system board package contains the following items. If any of these items are missing or damaged, please contact your dealer or sales representative for assistance.

- ☑ One SB100-NRM motherboard
- ☑ Two Serial ATA data cables
- ☑ One Serial ATA power cable
- ☑ One USB port cable
- \square One COM port cable (with bracket)
- ☑ One I/O shield
- ☑ One QR (Quick Reference)

The system board and accessories in the package may not come similar to the information listed above. This may differ in accordance to the sales region or models in which it was sold. For more information about the standard package in your region, please contact your dealer or sales representative.

Optional Items

- ☑ USB port cable
- ☑ COM port cable
- ☑ Serial ATA data cable
- ☑ Serial ATA power cable
- ☑ PS/2 Keyboard/Mouse cable
- ☑ IDE cable

The system board and accessories in the package may not come similar to the information listed above. This may differ in accordance to the sales region or models in which it was sold. For more information about the standard package in your region, please contact your dealer or sales representative.

Before Using the System Board

Before using the system board, prepare basic system components.

If you are installing the system board in a new system, you will need at least the following internal components.

- A CPU
- Memory module
- Storage devices such as hard disk drive, CD-ROM, etc.

You will also need external system peripherals you intend to use which will normally include at least a keyboard, a mouse and a video display monitor.

Specifications

Processor	 LGA 1155 socket for: 3rd generation Intel[®] Core[™] processors (22nm process technology) (Rev. AD0 or later) : Intel[®] Core[™] i7-3770 (8M Cache, up to 3.9GHz); 77W : Intel[®] Core[™] i5-3550S (6M Cache, up to 3.7GHz); 65W : Intel[®] Core[™] i3-3220 (3M Cache, 3.3GHz); 55W : Intel[®] Pentium[®] G2120 (3M Cache, 3.1 GHz); 65W 2nd generation Intel[®] Core[™] processors (32nm process technology) : Intel[®] Core[™] i7-2600 (8M Cache, up to 3.8 GHz); 95W : Intel[®] Core[™] i5-2400 (6M Cache, up to 3.4 GHz); 95W : Intel[®] Core[™] i3-2120 (3M Cache, 3.3 GHz); 65W : Intel[®] Pentium[®] G850 (3M Cache, 2.9 GHz); 65W • Intel[®] Advanced Vector Extensions (Intel[®] AVX) Instructions • Intel[®] Turbo Boost Technology
Chipset	• Intel [®] Q67 PCH (Platform Controller Hub)
System Memory	 Two 240-pin DDR3 DIMM sockets Supports DDR3 1333/1600MHz (3rd generation processors) Supports DDR3 1066/1333MHz (2nd generation processors) Supports up to 16GB system memory Supports dual channel memory interface DRAM device technologies: 1Gb, 2GB and 4Gb DDR3 DRAM technologies are supported for x8 and x16 devices, unbuffered, non-ECC
Expansion Slots	 1 PCIe x16 slot Supports Gen 3.0 (3rd generation processors) Supports Gen 2.0 (2nd generation processors)
Graphics	 Intel[®] HD Graphics Display ports: DVI-I (DVI-D signal) and VGA DVI-I supports up to 1920x1200 @ 60Hz resolution VGA supports up to 2048x1536 @ 75Hz resolution Supports 6 Graphics Execution Units (EUs) Intel[®] Clear Video Technology DirectX Video Acceleration (DXVA) support for accelerating video processing
Audio	 Realtek ALC262 2-channel High Definition Audio High performance DACs with 100dB SNR ADCs with 90dB SNR Two stereo DACs support 24-bit PCM format for stereo audio playback Three stereo ADCs support 20-bit PCM format for multiple input streaming S/PDIF audio interface
LAN	 Intel 82579LM with iAMT8.0 Gigabit Ethernet Phy Intel 82574L PCI Express Gigabit Ethernet controller Integrated 10/100/1000 transceiver Fully compliant with IEEE 802.3, IEEE 802.3u, IEEE 802.3ab

Serial ATA	 4 Serial ATA ports 2 SATA 2.0 ports with data transfer rate up to 3Gb/s 2 SATA 3.0 ports with data transfer rate up to 6Gb/s Integrated Advanced Host Controller Interface (AHCI) controller Supports RAID 0/1/5/10
Intel Active Management Technology (AMT)	 Supports iAMT8.0 Out-of-band system access Remote troubleshooting and recovery Hardware-based agent presence checking Proactive alerting Remote hardware and software asset tracking
TPM (optional)	 TPM - Trusted Platform Module Provides a Trusted PC for secure transactions Provides software license protection, enforcement and password protection
Rear Panel I/O Ports	 1 mini-DIN-6 PS/2 mouse port and PS/2 keyboard port 1 mini-DIN-6 PS/2 keyboard port 2 DB-9 serial ports Supports RS232/422/485 (RS232 and/or Power) 1 DB-15 VGA port 1 DVI-I port (DVI-D signal) 2 RJ45 LAN ports 4 USB 2.0/1.1 ports Mic-in, Line-in and Line-out jacks
I/O Connectors	 2 connectors for 4 external USB 2.0/1.1 ports 2 connectors for 2 external RS232 serial ports 1 8-bit Digital I/O connector 1 Digital I/O power connector 1 front audio connector for line-out and mic-in jacks 1 S/PDIF connector 4 Serial ATA ports 1 24-pin ATX power connector 1 4-pin 12V power connector 1 chassis intrusion connector 1 front panel connector 2 fan connectors
BIOS	• AMI BIOS - 64Mbit SPI BIOS
Energy Efficient Design	 Supports ErP Lot6 power saving (optional) Supports ACPI System Power Management Wake-On-Events include: Wake-On-PS/2 KB/Mouse Wake-On-USB KB/Mouse Wake-On-LAN RTC timer to power-on the system CPU stopped clock control AC power failure recovery

Damage Free Intelligence	 Monitors CPU/system temperature and overheat alarm Monitors VCORE/5V/3.3V/V_DIMM/12V/5VSB voltages and failure alarm Monitors CPU/system fan speed and failure alarm Read back capability that displays temperature, voltage and fan speed Watchdog timer function
Power	• 82.66 W with i7-2600 at 3.4GHz and 2x 2GB DDR3 DIMM
Consumption	
OS Support	 Windows XP Professional x86 & SP3 (32-bit) Windows XP Professional x64 & SP2 (64-bit) Windows 7 Ultimate x86 & SP1 (32-bit) Windows 7 Ultimate x64 & SP1 (64-bit) Windows 8 Enterprise x86 (32-bit) Windows 8 Enterprise x64 (64-bit)
Temperature	• 0°C to 60°C
Humidity	• 10% to 90%
Dimensions	 Mini-ITX form factor 170mm (6.7") x 170mm (6.7")
Certification	 CE FCC Class B UL RoHS KC

Features

Watchdog Timer

The Watchdog Timer function allows your application to regularly "clear" the system at the set time interval. If the system hangs or fails to function, it will reset at the set time interval so that your system will continue to operate.

DDR3

DDR3 delivers increased system bandwidth and improved performance. It offers peak data transfer rate of up to 21 Gb/s bandwidth. The advantages of DDR3 are its higher bandwidth and its increase in performance at a lower power than DDR2.

Graphics

The integrated Intel HD graphics for graphics intensive applications delivers exceptional 3D, 2D and video capabilities. It supports VGA and DVI interfaces.

DVI

DVI (Digital Visual Interface) is a form of video interface technology made to maximize the quality of flat panel LCD monitors and modern video graphics cards. Data is transmitted using the TMDS (Transition Minimized Differential Signaling) protocol, providing a digital signal from the PC's graphics subsystem to the display.

PCI Express

PCI Express is a high bandwidth I/O infrastructure that possesses the ability to scale speeds by forming multiple lanes. The x4 PCI Express lane supports transfer rate of 1 Gigabyte per second. The PCI Express architecture also provides a high performance graphics infrastructure by enhancing the capability of a x16 PCI Express lane to provide 8 Gigabytes per second transfer rate.

Intel Active Management Technology (AMT)

Intel Active Management Technology (Intel[®] AMT) allows remote access and management of networked systems even while PCs are powered off, remotely repair systems after OS failures and has the capability to remotely update all systems with the latest security software.

Audio

The Realtek ALC262 audio codec provides 2-channel High Definition audio output.

Serial ATA

Serial ATA is a storage interface that is compliant with SATA 1.0a specification. SATA 3.0 supports speed up to 6Gb/s while SATA 2.0 supports speed up to 3Gb/s. This improves hard drive performance faster than the standard parallel ATA whose data transfer rate is 100MB/s. The board supports RAID 0/1/5/10.

Gigabit LAN

The Intel W82579LM PHY and Realtek RTL8111DL PCI Express Gigabit controllers support up to 1Gbps data transmission.

USB

The system board supports USB 2.0 and USB 1.1 ports. USB 1.1 supports 12Mb/ second bandwidth while USB 2.0 supports 480Mb/second bandwidth providing a marked improvement in device transfer speeds between your computer and a wide range of simultaneously accessible external Plug and Play peripherals.

Wake-On-LAN

This feature allows the network to remotely wake up a Soft Power Down (Soft-Off) PC. It is supported via the onboard LAN port or via a PCI LAN card that uses the PCI PME (Power Management Event) signal. However, if your system is in the Suspend mode, you can power-on the system only through an IRQ or DMA interrupt.



Important:

The 5V_standby power source of your power supply must support \geq 720mA.

Wake-On-PS/2

This function allows you to use the $\mathsf{PS/2}$ keyboard or $\mathsf{PS/2}$ mouse to power-on the system.



Important:

The 5V_standby power source of your power supply must support \geq 720mA.

Wake-On-USB

This function allows you to use a USB keyboard or USB mouse to wake up a system from the S3 (STR - Suspend To RAM) state.



Important:

If you are using the Wake-On-USB Keyboard/Mouse function for 2 USB ports, the 5V_standby power source of your power supply must support \geq 1.5A. For 3 or more USB ports, the 5V_standby power source of your power supply must support \geq 2A.

RTC Timer

The RTC installed on the system board allows your system to automatically power-on on the set date and time.

ACPI STR

The system board is designed to meet the ACPI (Advanced Configuration and Power Interface) specification. ACPI has energy saving features that enables PCs to implement Power Management and Plug-and-Play with operating systems that support OS Direct Power Management. ACPI when enabled in the Power Management Setup will allow you to use the Suspend to RAM function.

With the Suspend to RAM function enabled, you can power-off the system at once by pressing the power button or selecting "Standby" when you shut down Windows[®] without having to go through the sometimes tiresome process of closing files, applications and operating system. This is because the system is capable of storing all programs and data files during the entire operating session into RAM (Random Access Memory) when it powers-off. The operating session will resume exactly where you left off the next time you power-on the system.



Important: The 5V_standby power source of your power supply must support \geq 720mA.

Power Failure Recovery

When power returns after an AC power failure, you may choose to either poweron the system manually or let the system power-on automatically.

Chapter 2 - Hardware Installation

System Board Layout





Important:

Electrostatic discharge (ESD) can damage your system board, processor, disk drives, add-in boards, and other components. Perform the upgrade instruction procedures described at an ESD workstation only. If such a station is not available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the system chassis. If a wrist strap is unavailable, establish and maintain contact with the system chassis throughout any procedures requiring ESD protection.

System Memory



Important:

When the Standby Power LED lit red, it indicates that there is power on the system board. Power-off the PC then unplug the power cord prior to installing any devices. Failure to do so will cause severe damage to the motherboard and components.



Features

- Two 240-pin DDR3 DIMM sockets
- Supports DDR3 1066/1333/1600MHz
- Supports dual channel memory interface
- Supports up to 16GB system memory

The system board supports the following memory interface.

Single Channel (SC)

Data will be accessed in chunks of 64 bits (8B) from the memory channels.

Dual Channel (DC)

Data will be accessed in chunks of 128 bits from the memory channels. Dual channel provides better system performance because it doubles the data transfer rate.

Installing the DIM Module

Note: The system board used in the following illustrations may not resemble the actual board. These illustrations are for reference only.

- 1. Make sure the PC and all other peripheral devices connected to it has been powered down.
- 2. Disconnect all power cords and cables.
- 3. Locate the DIMM socket on the system board.
- 4. Push the "ejector tabs" which are at the ends of the socket to the side.



5. Note how the module is keyed to the socket.



6. Grasping the module by its edges, position the module above the socket with the "notch" in the module aligned with the "key" on the socket. The keying mechanism ensures the module can be plugged into the socket in only one way.



7. Seat the module vertically, pressing it down firmly until it is completely seated in the socket.



8. The ejector tabs at the ends of the socket will automatically snap into the locked position to hold the module in place.



CPU

1

The system board is equipped with a surface mount LGA 1155 socket. This socket is exclusively designed for installing a LGA 1155 packaged Intel CPU.

Important:

- 1. Before you proceed, make sure (1) the LGA 1155 socket comes with a protective cap, (2) the cap is not damaged and (3) the socket's contact pins are not bent. If the cap is missing or the cap and/or contact pins are damaged, contact your dealer immediately.
- 2. Make sure to keep the protective cap. RMA requests will be accepted and processed only if the LGA 1155 socket comes with the protective cap.





Note:

The system board used in the following illustrations may not resemble the actual board. These illustrations are for reference only.

Installing the CPU

- 1. Make sure the PC and all other peripheral devices connected to it has been powered down.
- 2. Disconnect all power cords and cables.
- 3. Locate the LGA 1155 CPU socket on the system board.

Important:

The CPU socket must not come in contact with anything other than the CPU. Avoid unnecessary exposure. Remove the protective cap only when you are about to install the CPU.

 Unlock the socket by pushing the load lever down, moving it sideways until it is released from the retention tab; then lift the load lever up.





2

5. Lifting the load lever will at the same time lift the load plate.

Lift the load lever up to the angle shown on the photo.

Load lever



6. Remove the protective cap from the CPU socket. The cap is used to protect the CPU socket against dust and harmful particles. Remove the protective cap only when you are about to install the CPU.





7. Insert the CPU into the socket. The gold triangular mark on the CPU must align with the corner of the CPU socket shown on the photo.





The CPU's notch will at the same time fit into the socket's alignment key.

Important:

The CPU will fit in only one orientation and can easily be inserted without exerting any force.

Alignment key



Alignment key



2

8. Close the load plate then push the load lever down.

While closing the load plate, make sure the front edge of the load plate slides under the retention knob.

9. Hook the load lever under the retention tab.



Retention knob



24

Installing the Fan and Heat Sink

The CPU must be kept cool by using a CPU fan with heat sink. Without sufficient air circulation across the CPU and heat sink, the CPU will overheat damaging both the CPU and system board.



A boxed Intel[®] processor already includes the CPU fan and heat sink assembly. If your CPU was purchased separately, make sure to only use Intel[®]-certified fan and heat sink.

1. Before you install the fan / heat sink, you must apply a thermal paste onto the top of the CPU. The thermal paste is usually supplied when you purchase the fan / heat sink assembly. Do not spread the paste all over the surface. When you later place the heat sink on top of the CPU, the compound will disperse evenly.

Some heat sinks come with a patch of pre-applied thermal paste. Do not apply thermal paste if the fan / heat sink already has a patch of thermal paste on its underside. Peel the strip that covers the paste before you place the fan / heat sink on top of the CPU.

 Place the heat sink on top of the CPU. The 4 pushpins around the heat sink, which are used to secure the heat sink onto the system board, must match the 4 mounting holes around the socket.



 Orient the heat sink such that the CPU fan's cable is nearest the CPU fan connector.



4. Rotate each push-pin according to the direction of the arrow shown on top of the pin.

> Push down two pushpins that are diagonally across the heat sink. Perform the same procedure for the other two push-pins.



 Connect the CPU fan's cable to the CPU fan connector on the system board.



Jumper Settings

Clear CMOS Data



If you encounter the following,

- a) CMOS data becomes corrupted.
- b) You forgot the supervisor or user password.

you can reconfigure the system with the default values stored in the ROM BIOS.

To load the default values stored in the ROM BIOS, please follow the steps below.

- 1. Power-off the system and unplug the power cord.
- 2. Set JP9 pins 2 and 3 to On. Wait for a few seconds and set JP9 back to its default setting, pins 1 and 2 On.
- 3. Now plug the power cord and power-on the system.

2

Hardware Installation

PS/2 Power Select



JP2 is used to select the power of the PS/2 keyboard and PS/2 mouse ports. Selecting +5V_standby will allow you to use the PS/2 keyboard or PS/2 mouse to wake up the system.



USB Power Select



These jumpers are used to select the power of the USB ports. Selecting $+5V_{standby}$ will allow you to use a USB device to wake up the system.



Important:

If you are using the Wake-On-USB Keyboard/Mouse function for 2 USB ports, the +5V_standby power source of your power supply must support \geq 1.5A. For 3 or more USB ports, the +5V_standby power source of your power supply must support \geq 2A.

Power-on Select



To power-on via WOL after G3:

- 1. Set JP8 pins 2 and 3 to On.
- 2. Set the "After G3" field to **Power Off/WOL**.
- 3. Set the "GbE Wake Up From S5" to Enabled.

The BIOS fields are in the "South Bridge Configuration" submenu (Chipset menu) of the AMI BIOS utility.

To power-on via AC Power:

- 1. Set JP8 pins 2 and 3 to On.
- 2. Set the "After G3" field to **Power On**.

COMI/COM2 RS232/RS422/RS485 Select



JP1 (for COM1) and JP6 (for COM2) are used to configure the COM ports to RS232, RS422 (Full Duplex) or RS485.

The pin function of the COM ports will vary according to the jumper's setting.



COMI/COM2 RS232/Power Select



Rear Panel I/O Ports



The rear panel I/O ports consist of the following:

- PS/2 mouse port
- PS/2 keyboard port
- 2 COM ports
- VGA port
- DVI-I port (DVI-D signal only)
- 2 LAN ports
- 4 USB ports
- Mic-in jack
- Line-in jack
- Line-out jack

PS/2 Mouse and PS/2 Keyboard Ports



These ports are used to connect a PS/2 mouse and a PS/2 keyboard. The PS/2 mouse port uses IRQ12.

Wake-On-PS/2 Keyboard/Mouse

The Wake-On-PS/2 Keyboard/Mouse function allows you to use the PS/2 keyboard or PS/2 mouse to power-on the system. To use this function:

• Jumper Setting

JP2 must be set to "2-3 On: +5V_standby". Refer to "PS/2 Power Select" in this chapter for more information.

BIOS Setting

Configure the PS/2 keyboard/mouse wake up function in the Advanced menu ("ACPI Power Management Configuration" submenu) of the BIOS. Refer to chapter 3 for more information.



Important:

The +5V_standby power source of your power supply must support \geq 720mA.

COM (Serial) Ports



COM 3 and COM 4 are fixed at RS232.

The pin function of COM 1 and COM 2 ports will vary according to JP1/JP6's setting. Refer to "COM1/COM2 RS232/RS422/RS485 Select" in this chapter for more information.

The serial ports are asynchronous communication ports with 16C550A-compatible UARTs that can be used with modems, serial printers, remote display terminals, and other serial devices.

Connecting External Serial Ports

Your COM port may come mounted on a card-edge bracket. Install the card-edge bracket to an available slot at the rear of the system chassis then insert the serial port cable to the COM connector. Make sure the colored stripe on the ribbon cable is aligned with pin 1 of the COM connector.

BIOS Setting

Configure the serial ports in the Advanced menu ("Super IO Configuration" submenu) of the BIOS. Refer to chapter 3 for more information.

VGA Port



The VGA port is used for connecting a VGA monitor. Connect the monitor's 15-pin D-shell cable connector to the VGA port. After you plug the monitor's cable connector into the VGA port, gently tighten the cable screws to hold the connector in place.

BIOS Setting

Configure VGA in the Chipset menu ("North Bridge Configuration" submenu) of the BIOS. Refer to chapter 3 for more information.

Driver Installation

Install the graphics driver. Refer to chapter 4 for more information.
DVI-I Port



The DVI-I port is used to connect an LCD monitor. This port supports DVI-D signal only.

Connect the display device's cable connector to the DVI-I port. After you plug the cable connector into the port, gently tighten the cable screws to hold the connector in place.

BIOS Setting

Configure the display device in the Chipset menu ("North Bridge Configuration" submenu) of the BIOS. Refer to chapter 3 for more information.

RJ45 LAN Ports



Features

- Intel 82579LM with iAMT7.0 Gigabit Ethernet Phy
- Intel 82574L PCI Express Gigabit Ethernet controller

The LAN ports allow the system board to connect to a local area network by means of a network hub.

BIOS Setting

Configure the onboard LAN in the Chipset menu ("South Bridge Configuration" submenu) of the BIOS. Refer to chapter 3 for more information.

Driver Installation

Install the LAN drivers. Refer to chapter 4 for more information.

USB Ports



USB allows data exchange between your computer and a wide range of simultaneously accessible external Plug and Play peripherals.

The system board is equipped with two onboard USB 2.0/1.1 ports. The two 10-pin connectors allow you to connect 4 additional USB 2.0/1.1 ports. The additional USB ports may be mounted on a card-edge bracket. Install the card-edge bracket to an available slot at the rear of the system chassis and then insert the USB port cables to a connector.

BIOS Setting

Configure the onboard USB in the Advanced menu ("USB Configuration" submenu) of the BIOS. Refer to chapter 3 for more information.

Driver Installation

You may need to install the proper drivers in your operating system to use the USB device. Refer to your operating system's manual or documentation for more information.

Wake-On-USB Keyboard/Mouse

The Wake-On-USB Keyboard/Mouse function allows you to use a USB keyboard or USB mouse to wake up a system from the S3 (STR - Suspend To RAM) state. To use this function:

• Jumper Setting

JP4 and/or JP7 must be set to "2-3 On: +5V_standby". Refer to "USB Power Select" in this chapter for more information.



Important:

If you are using the Wake-On-USB Keyboard/Mouse function for 2 USB ports, the +5V_standby power source of your power supply must support \geq 1.5A. For 3 or more USB ports, the +5V_standby power source of your power supply must support \geq 2A.

Audio



Rear Audio

The system board is equipped with 3 audio jacks. A jack is a one-hole connecting interface for inserting a plug.

- Mic-in Jack (Pink) This jack is used to connect an external microphone.
- Line-in Jack (Light Blue) This jack is used to connect any audio devices such as Hi-fi set, CD player, tape player, AM/FM radio tuner, synthesizer, etc.
- Line-out Jack (Lime)
 This jack is used to connect a headphone or external speakers.

Front Audio

The front audio connector allows you to connect to the second line-out and micin jacks that are at the front panel of your system.

BIOS Setting

Configure the onboard audio in the Chipset menu ("South Bridge" submenu) of the BIOS. Refer to chapter 3 for more information.

Driver Installation

Install the audio driver. Refer to chapter 4 for more information.

I/O Connectors

S/PDIF Connector



The S/PDIF connector is used to connect an external S/PDIF port. Your S/PDIF port may be mounted on a card-edge bracket. Install the card-edge bracket to an available slot at the rear of the system chassis then connect the audio cable to the S/PDIF connector. Make sure pin 1 of the audio cable is aligned with pin 1 of the S/PDIF connector.

Digital I/O Connectors



The Digital I/O connector provides powering-on function to external devices that are connected to these connectors.

Pin	Pin Assignment
1	DIO7
2	DIO6
3	DIO5
4	DIO4
5	DIO3
6	DIO2
7	DIO1
8	DIO0

SATA (Serial ATA) Connectors



Features

- SATA 0 and SATA 1 support data transfer rate up to 6Gb/s
- SATA 4 and SATA 5 support data transfer rate up to 3Gb/s
- Integrated Advanced Host Controller Interface (AHCI) controller
- Supports RAID 0, RAID 1, RAID 5 and RAID 10

The Serial ATA connectors are used to connect Serial ATA devices. Connect one end of the Serial ATA cable to a SATA connector and the other end to your Serial ATA device.

BIOS Setting

Configure the Serial ATA drives in the Advanced menu ("IDE Configuration" submenu) of the BIOS. Refer to chapter 3 for more information.

Cooling Fan Connectors



The fan connectors are used to connect cooling fans. The cooling fans will provide adequate airflow throughout the chassis to prevent overheating the CPU and system board components.

BIOS Setting

The Advanced menu ("Hardware Health Configuration" submenu) of the BIOS will display the current speed of the cooling fans. Refer to chapter 3 for more information.

Chassis Intrusion Connector



The board supports the chassis intrusion detection function. Connect the chassis intrusion sensor cable from the chassis to this connector. When the system's power is on and a chassis intrusion occurred, an alarm will sound. When the system's power is off and a chassis intrusion occurred, the alarm will sound only when the system restarts.

MyGuard Hardware Monitor

Install the "MyGuard Hardware Monitor" utility. By default, the chassis intrusion detection function is disabled. When enabled, a warning message will appear when the chassis is open. The utility can also be configured so that a beeping alarm will sound when the chassis is open. Refer to the "MyGuard Hardware Monitor" section in chapter 4 for more information.

Power Connectors



Use a power supply that complies with the ATX12V Power Supply Design Guide Version 1.1. An ATX12V power supply unit has a standard 24-pin ATX main power connector that must be inserted into the 24-pin connector. The 4-pin +12V power connector enables the delivery of more +12VDC current to the processor's Voltage Regulator Module (VRM).

The power connectors from the power supply unit are designed to fit the 24-pin and 4-pin connectors in only one orientation. Make sure to find the proper orientation before plugging the connectors.

The system board requires a minimum of 300 Watt power supply to operate. Your system configuration (CPU power, amount of memory, add-in cards, peripherals, etc.) may exceed the minimum power requirement. To ensure that adequate power is provided, we strongly recommend that you use a minimum of 400 Watt (or greater) power supply.



Important:

Insufficient power supplied to the system may result in instability or the add-in boards and peripherals not functioning properly. Calculating the system's approximate power usage is important to ensure that the power supply meets the system's consumption requirements.

Standby Power LED



This LED will light red when the system is in the standby mode. It indicates that there is power on the system board. Power-off the PC and then unplug the power cord prior to installing any devices. Failure to do so will cause severe damage to the motherboard and components.

Front Panel Connectors



HDD-LED - HDD LED

This LED will light when the hard drive is being accessed.

RESET SW - Reset Switch

This switch allows you to reboot without having to power off the system.

PWR-BTN - Power Switch

This switch is used to power on or off the system.

PWR-LED - Power/Standby LED

When the system's power is on, this LED will light. When the system is in the S1 (POS - Power On Suspend) state, it will blink every second. When the system is in the S3 (STR - Suspend To RAM) state, it will blink every 4 seconds.

	Pin	Pin Assignment		Pin	Pin Assignment
HDD-LED	3	HDD Power	PWR-LED	2	LED Power
	5	Signal		4	LED Power
RESET SW	7	Ground		6	Signal
	9	RST Signal	PWR-BTN	8	Ground
	11	N.C.		10	Signal

Expansion Slots

2



PCI Express x16 Slot

Install PCI Express x16 graphics card, that comply to the PCI Express specifications, into the PCI Express x16 slot. To install a graphics card into the x16 slot, align the graphics card above the slot then press it down firmly until it is completely seated in the slot. The retaining clip of the slot will automatically hold the graphics card in place.

Battery



The lithium ion battery powers the real-time clock and CMOS memory. It is an auxiliary source of power when the main power is shut off.

Safety Measures

- Danger of explosion if battery incorrectly replaced.
- Replace only with the same or equivalent type recommend by the manufacturer.
- Dispose of used batteries according to local ordinance.

Chapter 3 - BIOS Setup

Overview

The BIOS is a program that takes care of the basic level of communication between the CPU and peripherals. It contains codes for various advanced features found in this system board. The BIOS allows you to configure the system and save the configuration in a battery-backed CMOS so that the data retains even when the power is off. In general, the information stored in the CMOS RAM of the EEPROM will stay unchanged unless a configuration change has been made such as a hard drive replaced or a device added.

It is possible that the CMOS battery will fail causing CMOS data loss. If this happens, you need to install a new CMOS battery and reconfigure the BIOS settings.

Note: The BIOS is constantly updated to improve the performance of the system board; therefore the BIOS screens in this chapter may not appear the same as the actual one. These screens are for reference purpose only.

Default Configuration

Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.

Entering the BIOS Setup Utility

The BIOS Setup Utility can only be operated from the keyboard and all commands are keyboard commands. The commands are available at the right side of each setup screen.

The BIOS Setup Utility does not require an operating system to run. After you power up the system, the BIOS message appears on the screen and the memory count begins. After the memory test, the message "Press DEL to run setup" will appear on the screen. If the message disappears before you respond, restart the system or press the "Reset" button. You may also restart the system by pressing the <Ctrl> <Alt> and keys simultaneously.

Legends

Keys	Function
Right and Left arrows	Moves the highlight left or right to select a menu.
Up and Down arrows	Moves the highlight up or down between submenus or fields.
<esc></esc>	Exits to the BIOS Setup Utility.
+ (plus key)	Scrolls forward through the values or options of the highlighted field.
- (minus key)	Scrolls backward through the values or options of the highlighted field.
Tab	Selects a field.
<f1></f1>	Displays General Help.
<f4></f4>	Saves and exits the Setup program.
<enter></enter>	Press <enter> to enter the high- lighted submenu.</enter>

Scroll Bar

When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.

Submenu

When " \blacktriangleright " appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press <Enter>.

AMI BIOS Setup Utility

Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.

Aptio Se	tup Utility - Copyrigl	ht (C) 2011	American Megat	rends, Inc.
Main Advanced	Chipset Boot	Security	Save & Exit	
BIOS Information BIOS Vendor Core Version Compliency Project Version Build Date and Time System Language System Date System Time Access Level	Ame: 4.6.5 UEFI 1AP] 09/06 [Engl [Fri ([15:0 Adm	rican Megatı .3 I 2.3; PI 1.2 IC 0.20 x64 5/2012 20:58 lish] 09/07/2012] 11:04] inistrator	rends	Choose the system default language. → ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt.
				F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends. Inc.				

System Language

Choose the system default language.

System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Sunday to Saturday. Month displays the month, from January to December. Date displays the date, from 1 to 31. Year displays the year, from 1980 to 2099.

System Time

The time format is <hour>, <minute>, <second>. The time is based on the 24hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.

Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.



	Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit	
 ACP11 PC He; Trustec CPU C SATA 0 Intel T AMT 0 USB 0 F71879 F81217 Network 	Power Managen alth Status I Computing onfiguration Configuration XT(LT) Configu Configuration onfiguration 9 Super IO Conf 7 Second Super % Stack	nent Configur ration iguration IO Configura	ration			ACPI Power Management Configuration. →←: Select Screen ↑↓: Select Item
						Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.						

Launch PXE OpROM

Enables or disables the boot option for legacy network devices.

Launch Storage OpROM

Enables or disables the boot option for legacy mass storage devices with option ROM.

ACPI Power Management Configuration

This section is used to configure the ACPI Power Management.

Aptio Setup Utility - Copy	right (C) 2011 American Megati	rends, Inc.
Advanced		
ACPI Power Management Configuration		Select the highest ACPI
ACPI Sleep State	[S1 (CPU Stop Clock)]	enter, when the SUSPEND button is pressed
Resume by PME	[Enabled]	button is pressed.
Resume by PS2 KB (S1, S3)	[Disabled]	
Resume by Ring	[Disabled]	
Resume by RTC Alarm	[Disabled]	
		$\rightarrow \leftarrow$: Select Screen
		↑↓: Select Item
		+/-: Change Opt.
		F1: General Help
		F2: Previous Values F3: Optimized Defaults
		F4: Save & Exit
		ESC: Exit
Version 2.14.1219. Copy	right (C) 2011 American Megatren	ids, Inc.

ACPI Sleep State

Selects the highest ACPI sleep state the system will enter when the Suspend button is pressed.

S1(POS) Enables the Power On Suspend function.

S3(STR) Enables the Suspend to RAM function.

Resume by PME

Enable this field to use the PME signal to wake up the system.

Resume by PS2 KB (S1, S3)

About resume by PS2 KB (S1, S3); Options are enabled or disabled.

Resume by PS2 MS (S1, S3)

About resume by PS2 MS (S1, S3); Options are enabled or disabled.

Resume by Ring

Set this field to Enabled to use the modem ring-on function. This will allow your system to power-on to respond to calls coming through an external or internal modem.

Resume by RTC Alarm

When Enabled, the system uses the RTC to generate a wakeup event.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

This section displays the SIO hardware health monitor.

PC Health Status

Advanced		
System Hardware Monitor Smart Fan Function Case Open Beep CPU Temperature System Temperature CPU FAN Speed System FAN Speed Vcore +5.0V +12V VDIMM +3.3V VS5V	[Disabled] : +57 C : +40 C : 5535 RPM : N/A : +1.032 V : +4.952 V : +12.144 V : +1.552 V : +3.248 V : +5.032V	Smart Fan Function → ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2	14.1219. Copyright (C) 2011 American Megatren	ds, Inc.

Smart Fan Function

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.			
Advanced			
CPU Smart Fan Control Boundary 1 Boundary 2 Boundary 3 Boundary 4 Speed Count 1 Speed Count 2 Speed Count 3 Speed Count 5 System Smart Fan(1) Control Boundary 1 Boundary 2 Boundary 3 Boundary 4 Speed Count 1 Speed Count 1 Speed Count 3 Speed Count 3 Speed Count 4 Speed Count 4 Speed Count 5	[Automatic] 60 50 40 30 100 75 50 40 30 [Automatic] 60 50 40 30 100 75 50 40 30 100 75 50 40 30 100 30 100 75 50 40 30 100 50 40 30 100 50 40 30 100 50 40 30 100 50 50 40 30 100 50 50 40 30 100 50 50 40 30 100 50 50 40 30 100 50 50 40 30 100 50 50 40 30 100 50 50 40 30 100 50 50 40 30 100 50 50 40 30 100 50 50 40 30 100 50 50 40 30 100 50 50 40 30 100 50 40 30 100 50 40 30 100 50 40 30 100 50 40 30 100 50 40 30 100 30 100 50 40 30 100 30 100 50 40 30 100 30 100 50 40 30 100 75 50 40 30 100 75 50 40 30 100 75 50 40 30 100 75 50 40 30 100 75 50 40 30 100 75 50 40 30 100 30 100 30 100 30 100 30 100 30 100 30 100 30 100 30 100 30 100 30 100 30 100 30 100 30 100 30 100 30 100 10	→ ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.			

CPU Smart Fan Control

When this feature is set to Automatic, the CPU's fan speed will rotate according to the CPU's temperature. The higher the temperature, the faster the speed of rotation.

Boundary 1 to Boundary 4

The range is from 0-127.

Speed Count 1 to Speed Count 5

The range is from 1-100.

Case Open Beep

Set this field to Enabled to allow the system to alert you of a chassis intrusion event.

Trusted Computing (optional)

This section configures settings relevant to Trusted Computing innovations.

Aptio Setup Utility - Copyright (C) 2010 American Megatrends, Inc.			
Advanced			
Configuration Security Device Support	[Disabled]	Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG	
Current Status Information NO Security Device Found		EFI protocol and INT1A interface will not be available.	
		→ \leftarrow : Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
Version 2.02.1205. Copyright (C) 2010 American Megatrends, Inc.			

TPM Support

Enables or Disables TPM. O.S. will not show TPM. Resetting the platform is required.

CPU Configuration

This section is used to configure the CPU. It will also display the detected CPU information.

	opyright (C) 2011 America	n Megatrends, Inc.	
Advanced			
CPU Configuration Intel (R) Core (TM) i7-3770S CPU @ 3.4 CPU Signature Microcode Patch Max CPU Speed Min CPU Speed CPU Speed Processor Cores Intel HT Technology Intel VT-x Technology	40GHz 306a8 10 3400 MHz 1600 MHz 3400 MHz 4 Supported Supported	Enabled for Windows XP and Linux (OS Optimised for Hyper-Threading Technology) and Disabled for other OS (OS not optimized for Hyper- Threading Technology) When disabled only one thread per enabled core is enabled.	
64-bit	Supported	$\rightarrow \leftarrow$: Select Screen	
L1 Data Cache L1 Code Cache L2 Cache L3 Cache	32 kB x 4 32 kB x 4 256 kB x 4 8192 kB	Enter: Select Hell +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults	
Hyper-Threading Active Processor Cores Intel Virtualization Technology	[Enabled] [All] [Disabled]	F4: Save & Exit ESC: Exit	
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.			

Active Processor Cores

Number of cores to enable in each processor package.

Intel Virtualization Technology

When this field is set to Enabled, the VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

SATA Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Advanced Enable or disable SATA SATA Mode Selection [IDE] device. Empty Unknown Serial ATA Port 0 Software Preserve Serial ATA Port 1 Empty Software Preserve Unknown Empty Unknown Serial ATA Port 4 Software Preserve Serial ATA Port 5 Empty Unknown Software Preserve Select Screen $\rightarrow \leftarrow$: $\uparrow\downarrow$: Select Item Enter: Select Change Opt +/-: F1: General Help F2: Previous Values F3: **Optimized Defaults** F4: Save & Exit ESC: Exit Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

This section is used to configure SATA functions.

SATA Mode

IDE Mode

This option configures the Serial ATA drives as Parallel ATA storage devices.

AHCI Mode

This option allows the Serial ATA devices to use AHCI (Advanced Host Controller Interface).

RAID Mode

This option allows you to create RAID or Intel Matrix Storage configuration on Serial ATA devices.

SATA Mode Selection

Determines how SATA controller(s) operate.

If AHCI or RAID is selected in the SATA Mode field, it will display the following information:

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.			
Advanced			
SATA Controller(s) SATA Mode Selection Aggressive LPM Support SATA Controller Speed	[Enabled] [AHCI] [Enabled] [Gen3]	▲ Determines how SATA controller(s) operate.	
SATA Controller Speed Serial ATA Port 0 Software preserve Port 0 Hot Plug External SATA SATA device type Spin up device Serial ATA Port 1 Software preserve Port 1 Hot Plug External SATA SATA device type Spin up device Serial ATA Port 2 Software preserve Port 2 Hot Plug External SATA Spin up device Serial ATA Port 3 Software preserve Port 3 Hot Plug External SATA Spin up device Serial ATA Port 3 Software preserve Port 3 Hot Plug External SATA Spin up device Serial ATA Port 4 Software preserve Port 4 Hot Plug External SATA	[Gen3] Empty Unknown [Enabled] [Disabled] [Disabled] [Hard Disk Driver] [Disabled] Empty Unknown [Enabled] [Disable	→ ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit nds, Inc.	
Spin up device Serial ATA Port 5 Software preserve Port 5 Hot Plug External SATA	[Disabled] Empty Unknown [Enabled] [Disabled] [Disabled]	Į	
spill up device			

Aggressive LPM Support

Enable PCH to aggressively enter link power state.

SATA Controller Speed

Indicates the maximum speed the SATA controller can support.

Serial ATA Port 0 to Serial ATA Port 5

These fields are used to configure the connected SATA devices.

Intel TXT (LT) Configuration

This section is used to configure the Intel Trusted Execution technology.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.				
Advanced				
Intel Trusted Execution Technology	Configuration			
Intel TXT support only can be enabl is enabled. VT and VT-d support mu prior to TXT.	ed/disabled if SMX st also be enabled			
Secure Mode Extension (SMX)	Enabled			
Intel TXT(LT) Support	[Disabled]			
		$\rightarrow \leftarrow$: Select Screen $\uparrow \downarrow$: Select Item		
		Enter: Select +/-: Change Opt.		
		F1: General Help		
		F3: Optimized Defaults		
		ESC: Exit		
Version 2.14.121	Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.			

Intel TXT(LT) Support

The options are Enabled and Disabled.

AMT Configuration

This section is used to configure the AMT function.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.						
Advanced						
Intel AMT MEBx Selection Screen Un-configure ME	[Enabled] [Disabled] [Disabled]	Enable or disable Intel (R) Active Management Tech- nology. Note: iAMT H/W is always enabled. This option just controls the BIOS extension execution. If enabled, this requires additional firmware in the SPI device.				
		 → ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit 				
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.						

MEBx Selection Screen

OEMFLag Bit 2: enable or disable MEBx selection screen.

Un-configure ME

OEMFLag Bit 15: Un-configure ME without password.

USB Configuration

This section is used to configure USB.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.				
Advanced				
USB Configuration		Enables Legacy USB support AUTO option		
USB Devices: 2 Hubs		disables legacy support if no USB devices are		
Legacy USB Support	[Enabled]	connected. DISABLE option will keep USB devices available only for		
	[1213dDieu]	EFI applications.		
		$\begin{array}{l} \rightarrow \leftarrow: \text{ Select Screen} \\ \uparrow \downarrow: \text{ Select Item} \end{array}$		
		Enter: Select +/-: Change Opt.		
		F1: General Help		
		F2: Previous Values F3: Optimized Defaults		
		F4: Save & Exit		
		ESC. EXIL		
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.				

Legacy USB Support

Enabled Enables legacy USB.

Auto

Disables support for legacy when no USB devices are connected.

Disabled

Keeps USB devices available only for EFI applications.

EHCI Hand-off

This is a workaround for OSes that does not support EHCI hand-off. The EHCI ownership change should be claimed by the EHCI driver.

F71879 Super IO Configuration

This section is used to configure the I/O functions supported by the onboard Super I/O chip.

Aptio Setup Utility - Co	pyright (C) 2011 American N	Megatrends, Inc.		
F71879 Super IO Configuration F71879 Super IO Chip Restore AC Power Loss WatchDog Timer Super IO WatchDog Timer	Fintek F71879 [Power Off] [Disabled] 10	Restore AC Power Loss help.		
		 → ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit 		
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.				

Restore AC Power Loss

Off

When power returns after an AC power failure, the system's power is off. You must press the Power button to power-on the system.

On

When power returns after an AC power failure, the system will automatically power-on.

Last State

When power returns after an AC power failure, the system will return to the state where you left off before power failure occurs. If the system's power is off when AC power failure occurs, it will remain off when power returns. If the system's power is on when AC power failure occurs, the system will power-on when power returns.

WatchDog Timer

This field is used to select the time interval of the Watchdog timer. If the system hangs or fails to function, it will reset at the set time interval so that your system will continue to operate.

F81217 Super IO Configuration

This section is used to configure the serial port functions.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.				
Advanced				
F81217 Second Super IO Configuration		Set Parameters of Serial Port 1 (COMA)		
 F81217 Second Super IO Chip Serial Port 1 Configuration Serial Port 2 Configuration Serial Port 3 Configuration Serial Port 4 Configuration 	781217 SecondIO			
		→ \leftarrow : Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit		
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.				

Serial Port 1 Configuration to Serial Port 4 Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Advanced				
Serial Port 1 Configuration Serial Port Device Settings Change Settings	[Enabled] IO=220h; IRQ=11; [Auto]	Enable or Disable Serial Port (COM)		
		→ ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit		
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.				

Serial Port

Enables or disables the serial port.

Change Settings

Selects the IO/IRQ setting of the I/O device.

Network Stack

This section configures settings relevant to the network stack Configuration.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.			
Advanced			
Network Stack	[Enabled]	Enable or disable UEFI network stack. → ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit	
Version 2.14.1219.	Copyright (C) 2011 American Megatren	ds, Inc.	

Chipset

Configures relevant chipset functions.

Aptio Setup Utility - Copyright (C) 2010 American Megatrends, Inc.						
Main	Advanced	Chipset	Boot	Security	Save & Exit	
 South I North I ME Su 	Bridge Bridge bsystem					North Bridge Parameters ←→: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.02.1205. Copyright (C) 2010 American Megatrends, Inc.						

South Bridge

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.				
Chipset				
Intel PCH RC Version Intel PCH SKU name Intel pCH Rev ID ▶ PCI Express Configuration ▶ USB Configuration	1.5.0.0 Q67 05/B3	PCI Express Configuration Settings.		
PCH 82579 LAN Controller Wake on LAN	[Enabled] [Enabled]			
High Precision Event Timer Configuration High Precision Timer	[Enabled]			
After G3	[Power on]	Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit		
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.				

PCH 82579 LAN Controller

Enables or disables LAN.

Wake on Lan

Enabled or disable intergrated LAN to wake the system. (The Wake On LAN cannot be disabled if ME is on at Sx state.)

High Precision Timer

Enables or disables the high precision event timer.

After G3

Power Off / WOL Power-on the system via WOL after G3. *Power On* Power-on the system after G3.

PCI Express Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.				
Chipset				
PCI Express Configuration		Enable/Disable LAN.		
OnBoard 82574 LAN Controller	[Auto]			
		→ \leftarrow : Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit		
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.				

USB Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.					
Chipset					
USB Configuration EHCI 1	[Enabled]	Control the USB EHCI (USB 2.0) functions. One EHCI controller must always be enabled.			
EHCI 2 USB Ports Per-Port Disable Control USB Port #0 Disable USB Port #1 Disable USB Port #2 Disable USB Port #3 Disable USB Port #4 Disable USB Port #5 Disable USB Port #8 Disable	[Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled]	$\rightarrow \leftarrow: Select Screen$ $\uparrow \downarrow: Select Item$ Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit			
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.					

EHCI Controller 1 and EHCI Controller 2

These fields are used to enable or disable Enhanced Host Controller Interface (USB 2.0).

USB Ports Per-Port Disable Control

Control each of the USB ports (0-13) disabling.

USB Port 0 to USB Port 9

Enables or disables the selected USB port.

North Bridge

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.				
Chipset				
System Agent Bridge Name System Agent RC Version VT-d Capability	Ivy Bridge 1.5.0.0 Supported	Check to enable VT-d function on MCH		
VT-d	[Enabled]			
 Graphics Configuration NB PCIe Configuration Memory Configuration 				
		→ \leftarrow : Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit		
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.				

VT-d

Check to enable VT-d function on MCH.
Graphics Configuration

Aptio Setup Util	ity - Copyright (C) 2011 America	n Megatrends, Inc.
Chipse	et	
Graphics Configuration IGFX VBIOS Version IGfx Frequency Primary Display Internal Graphics DVMT Pre-Allocated DVMT Total Gfx Mem	2137 350 MHz [Auto] [Auto] [64M] [256M]	Select which of IGFX/ PEG/PCI graphics device should be primary display or select SG for switch- able Gfx.
		→ \leftarrow : Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.14.1	219. Copyright (C) 2011 American	Megatrends, Inc.

Internal Graphics

Keep IGD enabled based on the setup options.

DVMT Pre-Allocated

Select DVMT 5.0 Pre-Allocated (Fixed) Graphics Memory size used by the internal graphics device.

DVMT Total Gfx Memory

Select DVMT 5.0 Total Graphics Memory size used by the internal graphics device.

NB PCIe Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Chipset								
NB PCIe Configuration PEG PEG- Gen x Enable PEG	Not Present [Gen1] [Enabled]	Configure PEG B0:D1:F0 Gen1-Gen3.						
		→ ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit						
Version 2.14.1	219. Copyright (C) 2011 American M	legatrends, Inc.						

Enable PEG

To enable or disable the PEG.

Memory Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Chipset								
Memory Information Memory RC Version Memory Frequency Total Memory DIMM#0 DIMM#1 CAS Latency (tCL) Minimum delay time CAS to RAS (tRCDmin) ROW Precharge (tRPmin) Active to Precharge (tRASmin) XMP Profile 1 XMP Profile 2	1.5.0.0 1333 Mhz 2048 MB (DDR3) Not Present 2048 MB (DDR3) 9 9 9 9 24 Not Supported Not Supported Not Supported	→ ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit						
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.								

ME Subsystem

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Chipset									
Intel ME Subsystem Configura	tion								
ME FW Version	8.0.4.1441	$\rightarrow \leftarrow: Select Screen$ $\uparrow \downarrow: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit$							
Version 2.1	4.1219. Copyright (C) 2011 American M	legatrends, Inc.							

Boot

Aptio Se	etup Utility - Copyri	ght (C) 2011	American Megat	rends, Inc.
Main Advanced	Chipset Boot	Security	Save & Exit	
Boot Configuration Setup Prompt Timeout Bootup NumLock State Quiet Boot CSM16 Module Version	[On] [Disabled] 07.69			Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.
Boot Option Priorities				
► CSM parameters				$\leftarrow \rightarrow$: Select Screen $\uparrow \downarrow$: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Versio	on 2.14.1219. Copyrig	tht (C) 2011	American Megatre	nds, Inc.

Setup Prompt Timeout

Selects the number of seconds to wait for the setup activation key. 65535(0xFFFF) denotes indefinite waiting.

Bootup NumLock State

This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on wherein the function of the numeric keypad is the number keys. When set to Off, the function of the numeric keypad is the arrow keys.

Quiet Boot

Enables or disables the quiet boot function.

CSM Parameters

Aptio Setup Utility - Co	pyright (C) 2011 American Meg	gatrends, Inc.
Bo	oot	
Launch CSM Boot option filter Launch PXE OpROM policy Launch Storage OpROM policy Other PCI device ROM priority	[Enabled] [UEFI and Legacy] [Do not launch] [Legacy only] [UEFI OpROM]	This option controls if CSM will be launched. ←→: Select Screen
		1↓: Select Item Enter: Select +/-: +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.14.1219. Co	pyright (C) 2011 American Mega	trends, Inc.

Boot option filter

This option controls what devices system can boot to.

Launch PXE OpROM policy

Controls the execution of UEFI and Legacy PXE OpROM.

Launch Storage OpROM policy

Controls the execution of UEFI and Legacy Storage OpROM.

Other PCI device ROM priority

For PCI devices other than Network, Mass storage or video defines which OpROM to launch.

Security

Α	ptio Se	etup Utility	- Copyrig	ght (C) 2011	American Megati	rends, Inc.		
Main Adva	nced	Chipset	Boot	Security	Save & Exit			
Password Descript	tion					Set Setup Administrator		
If ONLY the Administrator's password is set, Password then this only limits access to Setup and is only asked for when entering Setup. If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights. The password lenth must be in If ONLY the User's password lenth must be in								
Minimum lenth Maximum lenth		3 20				$\rightarrow \leftarrow$: Select Screen $\uparrow \downarrow$: Select Item Enter: Select		
Administrator Pass User Password	+/-: Change Opt. F1: General Help F2: Previous Values							
UEFI Secure Boot	Manag	gement				F3: Optimized Defaults F4: Save & Exit ESC: Exit		
	Versio	on 2.14.1219	. Copyrig	ht (C) 2011 A	American Megatrer	nds, Inc.		

Administrator Password

Sets the administrator password.

User Password

Sets the user password.

Save & Exit

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.										
Main Advanced	Chipset	Boot	Security	Save & Exit						
Save Changes and Reset Discard Changes and Res	et				Reset the system after saving the changes.					
Restore Defaults										
Boot Override										
Launch EFI Shell from fil	le system devid	ce								
					 ←→: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit 					
Versio	n 2.14.1219. C	Copyrig	tht (C) 2011	American Megatrer	ids, Inc.					

Save Changes and Reset

To save the changes, select this field and then press <Enter>. A dialog box will appear. Select Yes to reset the system after saving all changes made.

Discard Changes and Reset

To discard the changes, select this field and then press <Enter>. A dialog box will appear. Select Yes to reset the system setup without saving any changes.

Restore Defaults

To restore and load the optimized default values, select this field and then press <Enter>. A dialog box will appear. Select Yes to restore the default values of all the setup options.

Launch EFI Shell from file system device

Attempts to launch EFI shell application (Shellx64.efi) from one of the available filesystem devices.

Updating the BIOS

To update the BIOS, you will need the new BIOS file and a flash utility, AFUDOS. EXE. Please contact technical support or your sales representative for the files.

To execute the utility, type:

A:> AFUDOS BIOS_File_Name /b /p /n

then press <Enter>.

C:\AFU\AFUDOS>afudos filename	/B /P /N	
AMI Fi Copyright (C)2008	rmware Update Utility(APTIO) v2.25	
Reading file Erasing flash Writing flash Verifying flash Erasing BootBlock Writing BootBlock Verifying BootBlock	done done done done done done done	
C:\AFU\AFUDOS>		

Notice: **BIOS SPI ROM**

- 1. The Intel[®] Management Engine has already been integrated into this system board. Due to the safety concerns, the BIOS (SPI ROM) chip cannot be removed from this system board and used on another system board of the same model.
- 2. The BIOS (SPI ROM) on this system board must be the original equipment from the factory and cannot be used to replace one which has been utilized on other system boards.
- 3. If you do not follow the methods above, the Intel[®] Management Engine will not be updated and will cease to be effective.

Note:



- a. You can take advantage of flash tools to update the default configuration of the BIOS (SPI ROM) to the latest version anytime.
- b. When the BIOS IC needs to be replaced, you have to populate it properly onto the system board after the EEPROM programmer has been burned and follow the technical person's instructions to confirm that the MAC address should be burned or not.

Chapter 4 - Supported Software

Install drivers, utilities and software applications that are required to facilitate and enhance the performance of the system board. You may acquire the software from your sales representatives, from an optional DVD included in the shipment, or from the website download page at https://www.dfi.com/DownloadCenter.



Intel Chipset Software Installation Utility

The Intel Chipset Software Installation Utility is used for updating Windows $^{\mbox{\tiny B}}$ INF files so that the Intel chipset can be recognized and configured properly in the system.

To install the utility, click "Intel Chipset Software Installation Utility" on the main menu.

1. Setup is now ready to install the utility. Click Next.



2. Read the license agreement then click Yes.



 Go through the readme document for system requirements and installation tips then click Next.

el	ß	CI	nips	set	De	vic	e S	ioft	wa	ILLE	•		_		_	_	_			_	_	_	_	_	-			×
in Re	te ea	el ad	® me	C P F	hi ∹ile	ps e I	el nf	: C ori)e ma	vi at	ic Tic	e l	So	ftv	va	are		ののの問題		のないの	A CONTRACT	A State		(in	te)
Ref Pre * *	fei ess * *	r to ; th P1 Re	the e Pa	Re age ** uc	adn Dov ** t: e:	ne fi vn k ** Ii Pi	le t ey **	elov tov *** ≘1 (duc	vto iew R)	th	iew her ** Ch	the rest ** Ve	e sy: of ti set	tem nefi *** Dion	ire le. **	quir *** 7ic	**	** So	sar **	nd ir ** wa	sta * *	llati * *	on in * * *	for * *	mati **	on. * * *		
。 * * *	* *	Ve Te De	ers arg ate	10 et :	n: P Oc **	9 ro(to)	.2 du: oe: **	.U. Sts c C ***	10 14	1: 2: 2:	5 nt nd 01 **	el g .0	(R) ene	6 era	: 2 .ti	Ser lon	ie I	s/ nt **	C2 e1	00 (R **	3) **	er Co: **	ies ce(***	C TM **	hi])]	pse pro	:)) ;	
<	I																									>		
																<	Bac	k		٩	lex	: >			Ca	nce	(1
																				In	elŒ) In	stalla	itio	n Fr	ame	WOI	rk

4. Setup is now installing the driver. Click Next to continue.



5. Click "Yes, I want to restart this computer now" then click Finish.

> Restarting the system will allow the new software installation to take effect.



Microsoft DirectX 9.0C (for Windows XP only)

To install the utility, click "Microsoft DirectX 9.0C" on the main menu.

1. Click "I accept the agreement" then click Next.



 To start installation, click Next.

Install DirectX runtime components		2.
DirectX Runtime Install: This install package will search for up	dated DirectX Runtime Componer	its
To start installation, please click Next.	a rew minutes.	

 Click Finish. Reboot the system for DirectX to take effect.

Installing Microsoft(R) Dir	ectX(R)
	Installation Complete
	The components installed are now ready for use.
	< Back Finish Cancel

Microsoft .NET Framework 3.5 (for Windows XP only)

Note: Before installing Microsoft .NET Framework 3.5, make sure you have updated your Windows XP operating system to Service Pack 3.

To install the driver, click "Microsoft .NET Framework 3.5" on the main menu.

 Read the license agreement carefully.
 Microsoft .NET Framework 3.5 Setup

Click "I have read and accept the terms of the License Agreement" then click Install.



 Setup is now installing the driver.
 Microsoft .NET Framework 3.5 Setup



4

Supported Software

3. Click Exit.



Intel Graphics Drivers (for Windows Vista)

To install the driver, click "Intel Graphics Drivers" on the main menu.

 Setup is now ready to install the graphics driver. Click Next.
 Intel® Installation Framework Intel® HD Graphics



By default, the "Automatically run WinSAT and enable the Windows Aero desktop theme" is enabled. With this enabled, after installing the graphics driver and the system rebooted, the screen will turn blank for 1 to 2 minutes (while WinSAT is running) before the Windows Vista desktop appears. The "blank screen" period is the time Windows is testing the graphics performance.

We recommend that you Intel® Installation Framework skip this process by disabling this function then click Next. Welcome to the Setu



2. Read the license agreement Intel® Installation Framework then click Yes. Intel® HD Graphics



 Go through the readme document for system requirements and installation tips then click Next.

ntel® HD Graphics Drive			(intel
Refer to the Readme file below to view t	he system requirements .	and installation inf	ormation.
Microsoft Windows Vista* Microsoft Windows* 7			
Driver Revision: 15.21.3.2253			
December 3, 2010			
**************************************	*****************	*******	
* NOTE: This document refers to syste	ms containing the		1
	< Back	Next >	Cancel

 Setup is currently installing Intel® Installation Framework the driver. After installation has completed, click Next.



5. Click "Yes, I want to restart this computer now" then click Finish.

Restarting the system will allow the new software installation to take effect.



4

Supported Software

Intel Graphics Drivers (for Windows XP)

To install the driver, click "Intel Graphics Drivers" on the main menu.

1. Setup is ready to install the graphics driver. Click Next.



2. Read the license agreement then click Yes.



3. Go through the readme document for more installation tips then click Next.

ntel® Installation Framework		
ntel® HD Graphics Driver		itel
Refer to the Readme file below to view the	e system requirements and installation informa	tion.
**************************************	*****	
* Microsoft Windows* XP * Package: 110864 * * Graphics: 6.14.10.5313		
j" Uispiay Audio Univer: 5,14,00,30/4	< Back Next > C Intel® Installation	ancel Framework

4. Setup is currently installing the driver. After installation has completed, click Next.



5. Click "Yes, I want to restart this computer now." then click Finish.

> Restarting the system will allow the new software installation to take effect.

Intel® Installation Framework	
Intel® HD Graphics Driver	
Setup Is Complete	intel
You must restart this computer for the changes to take effect, computer now?	Would you like to restart the
Yes, I want to restart this computer now.	
○ No, I will restart this computer later.	
Click Finish, then remove any installation media from the drives.	
	Finish Intel® Installation Framework

Audio Drivers

To install the driver, click "Audio Drivers" on the main menu.

- 1. Setup is now ready to install the audio driver. Click Renated Technology of the Renated Tec
- Follow the remainder of the steps on the screen; clicking "Next" each time you finish a step.



Restarting the system will allow the new software installation to take effect.



Restation in a factor from the second from the	ear dering (2:51) 61 14 In Device Senar (2:51) 61 : 34 Fundatil Held Micael Complete Ster possible polytoper per seal and de al deal (Partie Held Deleter Sold) Device Senar phone and The pages, per seal and de al deal (Partie Held Deleter Sold) Device Senar (* Kaj 1 vel instantor ng company new Fundamentation of the device and the class Tools to company using	
t water of	- Sant Freeh	

LAN Drivers

To install the driver, click "LAN Drivers" on the main menu.

1. Setup is ready to install the driver. Click Next.



 Click "I accept the terms in the license agreement" then click "Next".

Please read the following license	e agreement carefully.	(intel)
INTEL SOFTWARE LI	CENSE AGREEMENT	(Final, License) 🚔
IMPORTANT - READ	<u>BEFORE COPYING, IN</u> <u>USING</u> .	NSTALLING OR
Do not use or load this materials (collectively,	s software and any as the "Software") until	sociated you have
carefully read the follo loading or using the S	owing terms and condi oftware, you agree to	itions. By the terms of this 🚽

 Select the program featuers you want installed then click Next.

install: Privers Intel(R) PROSet for Windows* Device Manager	
✓ Drivers ✓ Intel(R) PROSet for Windows* Device Manager	
└─ 🔽 Advanced Network Services └─ 🗌 Intel(R) Network Connections SNMP Agent	
Feature Description	

4. Click Install to begin the installation.



5. After completing installation, click Finish.

InstallShield Wizard Completed		(intel)
To access new features, open Device properties of the network adapters.	Manager, and view the	
InstallShield	Finish	Cancel

Intel Management Engine Interface

To install the driver, click "Intel Management Engine Interface" on the main menu.

1. Setup is ready to install the driver. Click Next.



2. Read the license agreement then click Yes.



3. Go through the readme document for more installation tips then click Next.



4. Setup is currently installing the driver. After installation has completed, click Next.



5. After completing installation, click Finish.



MyGuard Hardware Monitor

- 1. Locate for the MyGuard folder in the provided disc.
- In the MyGuard folder, right-click on the "setup" file.
- 3. Select Run As Administrator.
- 4. Double-click Setup.

Important:

Perform steps 1-3 only when using Windows 7 or Windows Vista.

5. Setup is ready to install the utility. Click Next.

Forunitat Townitat Townitat	Deter maidfiel Linit, store 7 am Pere Linit, store 7 am Pere	Type Contrast File 1428 File Contrast File Contrast File ERI Zin Configuration ERI File ERI Zin ERI Zin ERI Zin ERI Zin ERI Zin	Gan 53.64 53.64 645 645 143 143 144 144 144 144 144 144 144 144
---	--	---	---



6. Click Install to begin installation.



7. Setup is currently installing the utility.



8. After completing installation, click Finish to exit setup.



F6 Floppy Configuration Utility

This is used to create a floppy driver diskette needed when you install Windows[®] XP using the F6 installation method. This will allow you to install the operating system onto a hard drive when in AHCI mode.

- 1. Insert a blank floppy diskette.
- 2. Locate for the drivers in the CD then copy them to the floppy diskette. The CD includes drivers for both 32-bit and 64-bit operating systems. The path to the drivers are shown below.

32-bit CD Drive:\AHCI_RAID\F6FLOPPY\f6flpy32

64-bit CD Drive:\AHCI_RAID\F6FLOPPY\f6flpy64 4

Supported Software

Adobe Acrobat Reader 9.3

To install the reader, click "Adobe Acrobat Reader 9.3" on the main menu.

1. Click Next to install or click Change Destination Folder to select another folder.



2. Click Install to begin installation.



3. Click Finish to exit installation.



Infineon TPM Driver and Tool (optional)

To install the driver, click "Infineon TPM driver and tool (option)" on the main menu.

1. TPM requires installing the Microsoft Visual C++ package prior to installing the driver. Click Install.



2. The setup program is preparing to install the driver.



3. The setup program is ready to install the driver. Click Next.



4. Click "I accept the terms in the license agreement" and then click "Next".



5. Enter the necessary information and then click Next.

Sustomer Information		4
Please enter your information.		
User Name:		
Organization:		
18.50		
arsonand	-	

then click Next.



7. Click Install.



8. The setup program is currently installing the driver.



9. Click Finish.



10. Click Yes to restart the system.

Restarting the system will allow the new software installation to take effect.



Chapter 5 - RAID

The system board allows configuring RAID on Serial ATA drives. It supports RAID 0, RAID 1, RAID 5 and RAID 10.

RAID Levels

RAID 0 (Striped Disk Array without Fault Tolerance)

RAID 0 uses two new identical hard disk drives to read and write data in parallel, interleaved stacks. Data is divided into stripes and each stripe is written alternately between two disk drives. This improves the I/O performance of the drives at different channel; however it is not fault tolerant. A failed disk will result in data loss in the disk array.

RAID I (Mirroring Disk Array with Fault Tolerance)

RAID 1 copies and maintains an identical image of the data from one drive to the other drive. If a drive fails to function, the disk array management software directs all applications to the other drive since it contains a complete copy of the drive's data. This enhances data protection and increases fault tolerance to the entire system. Use two new drives or an existing drive and a new drive but the size of the new drive must be the same or larger than the existing drive.

RAID 5

RAID 5 stripes data and parity information across hard drives. It is fault tolerant and provides better hard drive performance and more storage capacity.

RAID 10 (Mirroring and Striping)

RAID 10 is a combination of data striping and data mirroring providing the benefits of both RAID 0 and RAID 1. Use four new drives or an existing drive and three new drives for this configuration.

Settings

RAID

To enable the RAID function, the following settings are required.

- 1. Connect the Serial ATA drives.
- 2. Configure Serial ATA in the AMI BIOS.
- 3. Configure RAID in the RAID BIOS.
- 4. Install the RAID driver during OS installation.
- 5. Install the Intel Rapid Storage Drivers.

Step 1: Connect the Serial ATA Drives

Refer to chapter 2 for details on connecting the Serial ATA drives.



Important:

- 1. Make sure you have installed the Serial ATA drives and connected the data cables otherwise you won't be able to enter the RAID BIOS utility.
- 2. Treat the cables with extreme caution especially while creating RAID. A damaged cable will ruin the entire installation process and operating system. The system will not boot and you will lost all data in the hard drives. Please give special attention to this warning because there is no way of recovering back the data.

Step 2: Configure Serial ATA in the AMI BIOS

- 1. Power-on the system then press to enter the main menu of the AMI BIOS.
- 2. Configure Serial ATA in the appropriate fields.
- 3. Save the changes in the Save & Exit menu.
- 4. Reboot the system.

Step 3: Configure RAID in the RAID BIOS

When the system powers-up and all drives have been detected, the Intel RAID BIOS status message screen will appear. Press the <Ctrl> and <I> keys simultaneously to enter the utility. The utility allows you to build a RAID system on Serial ATA drives.
RAID

Step 4: Install the RAID Driver During OS Installation

The RAID driver must be installed during the Windows[®] XP or Windows[®] 2000 installation using the F6 installation method. This is required in order to install the operating system onto a hard drive or RAID volume when in RAID mode or onto a hard drive when in AHCI mode.

- 1. Start Windows Setup by booting from the installation CD.
- 2. Press <F6> when prompted in the status line with the 'Press F6 if you need to install a third party SCSI or RAID driver' message.
- 3. Press <S> to "Specify Additional Device".
- 4. At this point you will be prompted to insert a floppy disk containing the RAID driver. Insert the RAID driver diskette.
- 5. Locate for the drive where you inserted the diskette then select RAID or AHCI controller that corresponds to your BIOS setup. Press <Enter> to confirm.

You have successfully installed the driver. However you must continue installing the OS. Leave the floppy disk in the floppy drive until the system reboots itself because Windows setup will need to copy the files again from the floppy disk to the Windows installation folders. After Windows setup has copied these files again, remove the floppy diskette so that Windows setup can reboot as needed. RAID

Step 5: Install the Intel Rapid Storage Drivers

The Intel Rapid Storage Drivers can be installed from within Windows. It allows RAID volume management (create, delete, migrate) from within the operating system. It will also display useful SATA device and RAID volume information. The user interface, tray icon service and monitor service allow you to monitor the current status of the RAID volume and/or SATA drives. It enables enhanced performance and power management for the storage subsystem.

- 1. Insert the provided CD into an optical drive.
- 2. Click "Intel Rapid Storage Technology for Raid/AHCI" on the main menu.
- 3. Setup is ready to install the utility. Click Next.



4. Read the warning carefully then click Next.



5. Read the license agreement then click Yes.



6. Go through the readme document to view system requirements and installation information then click Next.

Readme File Information	noogy	inter
Lefer to the Readme file below to view the Installation Readme for Instell(R) Rapid Storage Technology (Inte	system requirements and installation in	nformation.
* Refer to the system requirements for the * systems supported by Intel Rapid Storag	e operating ge Technology.	
* Refer to the system requirements for th * systems supported by Intel Rapid Storag * This document makes references to proc * Intel. There are some restrictions on how * may be used, and what information may o thers. Please read the Disclaimer sectio	e operating ge Technology. ducts developed by w these products 'be disclosed to n at the bottom	-

7. Setup is currently installing the driver. After installation has completed, click Next.



RAID

8. Click "Yes, I want to restart my computer now" then click Finish.



Chapter 6 - Intel AMT Settings

Overview

Intel Active Management Technology (Intel $^{\otimes}$ AMT) combines hardware and software solution to provide maximum system defense and protection to networked systems.

The hardware and software information are stored in non-volatile memory. With its built-in manageability and latest security applications, $Intel^{\mbox{\tiny B}}$ AMT provides the following functions.

Discover

Allows remote access and management of networked systems even while PCs are powered off; significantly reducing desk-side visits.

Repair

Remotely repair systems after OS failures. Alerting and event logging help detect problems quickly to reduce downtime.

• Protect

Intel AMT's System Defense capability remotely updates all systems with the latest security software. It protects the network from threats at the source by proactively blocking incoming threats, reactively containing infected clients before they impact the network, and proactively alerting when critical software agents are removed.

Enable Intel[®] AMT in the AMI BIOS

- 1. Power-on the system then press to enter the main menu of the AMI BIOS.
- 2. In the Advanced menu, select AMT Configuration.

MainAdvancedChipsetBootSecuritySave & Exit• ACPI Power Management Configuration • PC Health Status • Trusted Computing • CPU Configuration • SATA Configuration • Intel TXT(LT) Configuration • AMT Configuration • USB Configuration • F71879 Super IO Configuration • F81217 Second Super IO Configuration • Network StackACPI Power Management Configuration • Security • F81217 Second Super IO Configuration • Network StackACPI Power Management Configuration • F81217 Second Super IO Configuration • F81217 Second Super IO Configuration • Network Stack→ <-: Select Screen ↑↓: Select Item Enter: Select ·↓: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.					
 ACPI Power Management Configuration PC Health Status Trusted Computing CPU Configuration SATA Configuration Intel TXT(LT) Configuration AMT Configuration USB Configuration F71879 Super IO Configuration F81217 Second Super IO Configuration Network Stack → ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	Main Advanced	Chipset	Boot	Security	Save & Exit	
	 ACPI Power Managen PC Health Status Trusted Computing CPU Configuration SATA Configuration Intel TXT(LT) Configuration USB Configuration USB Configuration F71879 Super IO Configuration F81217 Second Super Network Stack 	ent Configu ration iguration IO Configur	ration			ACPI Power Management Configuration. → ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

3. In the Advanced menu, select Enable in the AMT field.

Aptio Setup U	Utility - Copyright (C) 2011 Amer	rican Megatrends, Inc.
Intel AMT MEBx Selection Screen Un-configure ME	[Enabled] [Disabled] [Disabled]	Enable or disable Intel (R) Active Management Tech- nology. Note: iAMT H/W is always enabled. This option just controls the BIOS extension execution. If enabled, this requires additional firmware in the SPI device.
		→ \leftarrow : Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		

6

4. In the Save & Exit menu, select Save Changes and Reset then select OK.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.						
Main	Advanced	Chipset	Boot	Security	Save & Exit	
Save Chan Discard Cl	iges and Reset hanges and Res	set				Reset the system after saving the changes.
Restore De	efaults					
Boot Over	ride					
Launch EF	FI Shell from f	le system de	vice			
						$\begin{array}{l} \leftarrow \rightarrow: \text{ Select Screen} \\ \uparrow\downarrow: \text{ Select Item} \\ \text{Enter: Select} \\ +/-: \text{ Change Opt.} \\ \text{F1: General Help} \\ \text{F2: Previous Values} \\ \text{F3: Optimized Defaults} \\ \text{F4: Save \& Exit} \\ \text{ESC: Exit} \end{array}$
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.						

Enable Intel[®] AMT in the Intel[®] Management Engine BIOS Extension (MEBX) Screen

1. When the system reboots, the following message will be displayed. Press <**Ctrl-P**> as soon as the message is displayed; as this message will be displayed for only a few seconds.



2. You will be prompted for a password. The default password is "**admin**". Enter the default password in the space provided under Intel(R) ME Password then press Enter.



- 3. Enter a new password in the space provided under Intel(R) ME New Password then press Enter. The password must include:
 - 8-32 characters
 - Strong 7-bit ASCII characters excluding : , and " characters
 - At least one digit character (0, 1, ...9)
 - At least one 7-bit ASCII non alpha-numeric character, above 0x20, (e.g. !, \$, ;)
 - Both lower case and upper case characters

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.		
Main Menu		
MEBx Login > Intel (R) ME General Settings > Intel (R) AMT Configuration MEBx Exit Intel (R) ME Password		
Intel (R) ME Password		
$[\uparrow\downarrow] =$ Move highlight [ENTER] = Select Entry [ESC]= Exit		

4. You will be asked to verify the password. Enter the same new password in the space provided under Verify Password then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.		
Main Menu		
MEBx Login > Intel (R) ME General Settings > Intel (R) AMT Configuration MEBx Exit Verify Password		
Intel (R) ME Password		
$[\uparrow\downarrow] =$ Move highlight [ENTER] = Select Entry [ESC]= Exit		

5. Select Intel(R) ME General Settings then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.		
Main Menu		
> Intel (R) ME General Settings > Intel (R) AMT Configuration MEBx Exit		
$[\uparrow\downarrow] =$ Move highlight [ENTER] = Select Entry [ESC]= Exit		

6. Select Change Intel(R) ME Password then press Enter.

You will be prompted for a password. The default password is "**admin**". Enter the default password in the space provided under Intel(R) ME New Password then press Enter.

- 8-32 characters
- Strong 7-bit ASCII characters excluding : , and " characters
- At least one digit character (0, 1, ...9)
- At least one 7-bit ASCII non alpha-numeric character, above 0x20, (e.g. !, \$, ;)
- Both lower case and upper case characters



7. Select Local FW Update then press Enter. Select Enabled then press Enter.



8. In the Intel(R) ME Platform Configuration menu, select Power Control then press Enter.



9. In the Intel(R) ME Power Control menu, select Intel(R) ME ON in Host Sleep States then press Enter. Select an option then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.		
INTEL (R) ME POWER CONTROL		
Intel (R) ME ON in Host Sleep States Idle Timeout	<desktop: in="" on="" s0=""> 1</desktop:>	
Desktop: ON in S0 Desktop: ON in S0, ME Wake in S3, S4	-5	
$[\uparrow\downarrow] =$ Move highlight [ENTER] = Select En	try [ESC]= Discard changes	

10. In the Intel(R) ME Power Control menu, select Idle Timeout then press Enter. Enter the timeout value.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.		
INTEL (R) ME POWER CONTROL		
Intel (R) ME ON in Host Sleep States <desttop in="" on="" s0="">Idle Timeout1</desttop>		
Timeout Value (1-65535) 1_		
<enter> = Complete Entry [ESC]= Discard Changes</enter>		

11. Select Previous Menu until you return to the Main Menu. Select Intel(R) AMT Configuration then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.			
INTEL (R) AMT CONFIGURATION			
Manageability Feature Selection > SOL/ IDER/ KVM > User Consent	< Enabled>		
Password Policy > Network Setup Activate Netwok Access	<anytime></anytime>		
Unconfigure Network Access > Remote Setup And Configuration	<full unprovision=""></full>		
$[\uparrow\downarrow] = Move highlight [ENTER]$] = Select Entry [ESC]= Exit		

12. In the Intel(R) AMT Configuration menu, select Manageability Feature Selection then press Enter. Select disabled then press Enter.



Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.			
	SOL/ IDER/ KVM		
Username and password SOL IDER KVM Feature Selection Legacy Redirection Mod	l < Enabled> <enabled> <enabled> <enabled> de <disabled></disabled></enabled></enabled></enabled>		
Menu for FW Redire	ection Configuration		
$[\uparrow\downarrow] = Move highlight$	[ENTER] = Select Entry	[ESC]= Exit	

14. In the **SOL/IDER/KVM** menu, select **Username and Password** then press Enter. Select disabled then press Enter.



15. In the **SOL/IDER/KVM** menu, select **SOL** then press Enter. Select disabled then press Enter.



16. In the **SOL/IDER/KVM** menu, select **IDER** then press Enter. Select disabled then press Enter.



17. In the **SOL/IDER/KVM** menu, select **KVM** then press Enter. Select disabled then press Enter.



18. In the **SOL/IDER/KVM** menu, select **Legacy Redirection Mode** then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.		
SOL/ IDER/ KVM		
Username and password	< Enabled>	
SOL	<enabled></enabled>	
IDER	<enabled></enabled>	
KVM Feature Selection	<enabled></enabled>	
Legacy Redirection Mode	<disabled></disabled>	
Menu for FW Redirection Configuration		
$[\uparrow\downarrow] = Move highlight [ENTER] = S$	elect Entry [ESC]= Exit	

6

Intel AMT Settings

19. Select Enabled then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved. SOL/ IDER/ KVM Username and password < Enabled> SOL <Enabled> IDER <Enabled> **KVM** Feature Selection <Enabled> <Disabled> Legacy Redirection Mode Disabled Enabled <ENTER> = Complete Entry [ESC]= Discard Changes

20. Select Previous Menu until you return to the Intel(R) AMT Configuration menu. Select User Consent then press Enter.



21. In the **User Consent Configuration** menu, select **User Opt-in** then press Enter. Select **None** then press Enter.



22. In the User Consent Configuration menu, select Opt-in Configurable from Remote IT then press Enter. Select Disable Remote Control of KVM Opt-in Policy then press Enter.



23. Select Previous Menu until you return to the Intel(R) AMT Configuration menu. Select Password Policy then press Enter.

You may choose to use a password only during setup and configuration or to use a password anytime the system is being accessed.



24. In the Intel(R) AMT Configuration menu, select Network Setup then press Enter.



25. In the Intel(R) Network Setup menu, select Intel(R) ME Network Name Settings then press Enter.



26. In the Intel(R) ME Network Name Settings menu, select Host Name then press Enter. Enter the computer's host name then press Enter.



27. Select **Domain Name** then press Enter. Enter the computer's domain name then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.
INTEL (R) ME NETWORK NAME SETTINGS
Host NameDomain NameShared/ Dedicated FQDN <shared>Dynamic DNS Update<disabled></disabled></shared>
Computer Domain Name
<enter> = Complete Entry [ESC]= Discard Changes</enter>

28. Select **Shared/Dedicated FQDN** then press Enter. Select Shared or Dedicated then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.
INTEL (R) ME NETWORK NAME SETTINGS
Host Name Domain Name Shared/ Dedicated FQDN Dynamic DNS Update <disabled> Dedicated shared</disabled>
<enter> = Complete Entry [ESC]= Discard Changes</enter>

29. Select **Dynamic DNS Update** then press Enter. Select Enabled or Disabled then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel Copyright(C) 2003-12 Intel Corporation. All Rights	(R) ME v8.0.4.1441 S Reserved.
INTEL (R) ME NETWORK NAME SETTI	NGS
Host Name	
<enter> = Complete Entry [ESC]=</enter>	Discard Changes

30. Select Previous Menu until you return to the Intel(R) ME Network Setup menu. Select TCP/IP Settings then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.
TCP/ IP SETTINGS
> Wired LAN IPV4 Configuration
$[\uparrow\downarrow] =$ Move highlight [ENTER] = Select Entry [ESC]= Exit

31. In the TCP/IP Settings menu, select Wired LAN IPV4 Configuration then press Enter.

Intel(R) Manager Copyrig	ment Engine BIOS Extension v8.0.0 ht(C) 2003-12 Intel Corporation.	0.0061/Intel(R) ME v8.0.4.1441 All Rights Reserved.
	WIRED LAN IPV4 CONFIG	JURATION
DHCP Mode	Disabled Enabled	<enabled></enabled>
	<enter> = Complete Entry</enter>	[ESC]= Discard Changes

32. Select Previous Menu until you return to the Intel(R) AMT Configuration menu. Select Activate Network Access then press Enter. Type Y then press Enter.

Intel(R) Management En Copyright(C) 20	gine BIOS Exte 003-12 Intel C	ension v8.0.0.0061/I orporation. All Ri	ntel(R) ME v8.0.4.1441 ghts Reserved.
IN	TEL (R) AMT	CONFIGURATIO	DN
Manageability Featur > SOL/ IDER/ KVM	e Selection	< Enal	oled>
 > User Consent Password Policy > Network Setup 	_	<anyti< td=""><td>me></td></anyti<>	me>
Activate Netwok Acc Unconfigure Netwo > Remote Setup And	ess Activiates the and opens the Co	current network so e ME netwotk inte ntinue: (Y/N)	on> erface
$[\uparrow\downarrow] = Move highlight$	[ENTER]	= Select Entry	[ESC]= Exit

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.		
INTEL (R) AMT CON	NFIGURATION	
Manageability Feature Selection > SOL/ IDER/ KVM	< Enabled>	
 > Oser Consent Password Policy > Network Setup Activate Netwok Access 	<anytime></anytime>	
Unconfigure Network Access > Remote Setup And Configuration	<full unprovision=""></full>	
Full Unprovi Partial Unprov	sion vision	
<enter> = Complete E</enter>	Entry [ESC]= Discard Changes	

34. In the Intel(R) AMT Configuration menu, select Remote Setup And Configuration then press Enter.



35. In the Intel(R) Automated Setup And Configuration menu, select Current Provisioning Mode then press Enter.

Intel(R) Manageme Copyright	nt Engine BIOS Extension v8.0.0.0061/Inte (C) 2003-12 Intel Corporation. All Righ	el(R) ME v8.0.4.1441 ts Reserved.
INTEL (R) AUTOMATED SETUP AND CONFI	GURATION
Current Provisi Provisioning Re Provisioning Se Provisioning Se > RCFG > TLS PSK > TLS PKI	oning Mode ecord erver IPV4/IPV6 _ erver FQDN _ Provisioning Mode:PKI	
$[\uparrow\downarrow] = Move high$	light [ENTER] = Select Entry	[ESC]= Exit

36. In the Intel(R) Automated Setup And Configuration menu, select Provisioning Record then press Enter.



37. Select Previous Menu until you return to the Intel(R) Automated Setup And Configuration menu. Select Provisioning Server IPV4/IPV6 then press Enter. Type server address then press Enter.



38. In the Intel(R) Automated Setup And Configuration menu, select Provisioning Server FQDN then press Enter. Type FQDN of provisioning server then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.
INTEL (R) AUTOMATED SETUP AND CONFIGURATION
Current Provisioning Mode Provisioning Record Provisioning Server IPV4/IPV6 Provisioning Server FQDN > RCFG > TLS PSK > TLS PKI Enter FQDN of provisioning server
<enter> = Complete Entry [ESC]= Discard Changes</enter>

39. In the Intel(R) Remote Configuration menu, select Start Configuration then press Enter. Type Y then press Enter.



40. In the Intel(R) Automated Setup And Configuration menu, select TLS PSK then press Enter.



41. In the Intel(R) Remote Configuration menu, select Set PID and PPS ** then press Enter. Type PID code then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.
INTEL (R) TLS PSK CONFIGURATION
Set PID and PPS **
Enter PID (e.g. ABCD-1234)
<enter> = Complete Entry [ESC]= Exit</enter>

42. In the Intel(R) Remote Configuration menu, select Delete PID and PPS ** then press Enter. Type Y then press Enter.



43. Select Previous Menu until you return to the Intel(R) Automated Setup And Configuration menu. Select TLS PKI then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.
INTEL (R) AUTOMATED SETUP AND CONFIGURATION
Current Provisioning Mode Provisioning Record Provisioning Server IPV4/IPV6 Provisioning Server FQDN > RCFG > TLS PSK > TLS PKI
$[\uparrow\downarrow] =$ Move highlight [ENTER] = Select Entry [ESC]= Exit

44. In the Intel(R) Remote Configuration menu, select Remote Configuration ** then press Enter. Select Disabled then press Enter.

Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.0.4.1441 Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.
INTEL (R) REMOTE CONFIGURATION
Remote Configuration ** <a>Enabled> PKI DNS Suffix - > Manage Hashes
<enter> = Complete Entry [ESC]= Discard Changes</enter>

45. In the Intel(R) Remote Configuration menu, select PKI DNS Suffix then press Enter. Type PKI DNS Suffix then press Enter.



46. In the Intel(R) Remote Configuration menu, select Manage Hashes then press Enter.

Intel(R) Management E	ngine BIOS Extension	n v8.0.0.0061/Intel(R) ME v8.0.4.1441
Copyright(C) 2	2005-12 Intel Corpo	oration. An Rights	Keserved.
INT	EL (R) REMOTE C	CONFIGURATION	1
Hash Name	Active	Default	Algorithm
VeriSign Class 3	Active: [*]	Default: [*]	SHA1
VeriSign Class 3	Active: [*]	Default: [*]	SHA1
Go Daddy Class 2	Active: [*]	Default: [*]	SHA1
Comodo AAA CA	Active: [*]	Default: [*]	SHA1
Starfield Class 2	Active: [*]	Default: [*]	SHA1
VeriSign Class 3	Active: [*]	Default: [*]	SHA1
VeriSign Class 3	Active: [*]	Default: [*]	SHA1
VeriSign Class 3	Active: [*]	Default: [*]	SHA1
GTE CyberTrust G1	Active: [*]	Default: [*]	SHA1
Baltimore Cyber Tr	Active: [*]	Default: [*]	SHA1
Cyber Trust Global	Active: [*]	Default: [*]	SHA1
Verizon Global Ro	Active: [*]	Default: [*]	SHA1
Entrust. net CA (2	Active: [*]	Default: [*]	SHA1
[Ins]= Add New ash [↑↓] =Move highlight	[Delete] = Delete Hash [ENTER] = View Hash	[+] = Activate H [Esc]= Exit	ash

47. Select Previous Menu until you return to the **Main Menu**. Select **Exit** then press Enter. Type **Y** then press Enter.



Appendix A - NLITE and AHCI Installation Guide

nLite

nLite is an application program that allows you to customize your XP installation disc by integrating the RAID/AHCI drivers into the disc. By using nLite, the F6 function key usually required during installation is no longer needed.



Note: The installation steps below are based on nLite version 1.4.9. Installation procedures may slightly vary if you're using another version of the program.

1. Download the program from nLite's offical website.

http://www.nliteos.com/download.html

2. Install nLite.



Important:

Due to it's coding with Visual.Net, you may need to first install .NET Framework prior to installing nLite.

3. Download relevant RAID/AHCI driver files from Intel's website. The drivers you choose will depend on the operating system and chipset used by your computer.

The downloaded driver files should include iaahci.cat, iaAHCI.inf, iastor.cat, iaStor. inf, IaStor.sys, license.txt and TXTSETUP.OEM.



NLITE and AHCI Installation Guide

- 4. Insert the XP installation disc into an optical drive.
- 5. Launch nLite. The Welcome screen will appear. Click **Next**.



 Click Next to temporarily save the Windows installation files to the designated default folder.

> If you want to save them in another folder, click **Browse**, select the folder and then click **Next**.



NLITE and AHCI Installation Guide

7. Click Next.



8. In the Task Selection dialog box, click **Drivers** and **Bootable ISO**. Click **Next**.

	lubgab	Sarves Pack
		Birfines, Add-our sal Uplete Fachs
		Dites
	Remove	Compresent
	Setup	theoremated
		O Options
		• Treats
	Carste	Bootable ISO

NLITE and AHCI Installation Guide

 Click Insert and then select Multiple driver folder to select the drivers you will integrate. Click Next.



 Select only the drivers appropriate for the Windows version that you are using and then click **OK**.

Integrating 64-bit drivers into 32-bit Windows or vice versa will cause file load errors and failed installation.


If you are uncertain of the southbridge chip used on your motherboard, select all RAID/AHCI controllers and then click OK.



12. Click Next.

1001 121 1001 121 1001 121 1001 121 1001 121 1001 121 1001 121 1001 121 1001 121 1001 127 1001 127 1001 127 1001 127 1001 127 1001 127 1001 127 1001 127 1001 127 1001 127	Ma Ma Ma Ma Ma Ma Ma Ma Ma Ma Ma Ma Ma M	8 9 0 1023 8 9 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0040000 CAHCI 00540000 CAHCI
lami IXI	biz	890.1023	DED42005 CANCI
lami IXI	biz	890.1023	DE042005 CANCI

13. The program is currently integrating the drivers and applying changes to the installation.



14. When the program is finished applying the changes, click **Next**.

Preparing selected tasks Integrating hotions, pocks and theman Remaining components Processing cotup lifes Integrating downs Finalizing
Integrating hotives, packy and themas Termaning components Processing onto Illes Integrating divers Finalizing
Remaining components Processing total lifes Integrating downs Finalizing
Processing cotup lifes Integrating device Finalizing
Integrating device Finalizing
Finalizing
Resided1 Totel ser is 657.77MB
Integrated Ariver: 0.1880B
The autholistics wave by 0 SdMB

15. To create an image, select the **Create Image** mode under the General section and then click **Next**.

General						
Mole	THE R.	Device				
Contr linige						11.4
Lobel		Box speed		Media		
Wollie				-		2
Advaged						
100 Eague		Boot anter			T day and	
Defealt	H	Detech	M 4	Wanty	Ter vite	
Ingen						
-				Cáck hen	to shart -> M	alar 130
Information.						
If you want to include the second	le additional files	on your CD/DVD,	copy them The later	ts the working due	rhay	

 Or you can choose to burn it directly to a disc by selecting the Direct Burn mode under the General section.

> Select the optical device and all other necessary settings and then click **Next**.

caldie			
Creek a bootster S7.7 to bias on U2/07	FLI or for to faile		7/1
			1 2
(Berna)			
Mole	Device		
Davet Base 🛩 😣	1.1 G.F. FIONEER, DVD-R	RW DVR-111D 1.23	* 8
Label	Box speed	Helin	
Walke	Maannan 💌	No media	8
Advant			
100 Engus	Boot autor	- Organia	
Delina 🔍 😣	Delect M Q	Terivite	
Ingan			
		Click here to stud -+	Pop
Information.			
29 you want to include additional filer before starting, or just click next if you	on your CD/DVD, copy them a weat to racke the \$50 lefts	h de voking dantery	appear]
1.000			
🙆 Tay		O het Met O	Gereal 🗙

17. You have finished customizing the Windows XP installation disc. Click **Finish**.

> Enter the BIOS utility to configure the SATA controller to RAID/AHCI. You can now install Windows XP.



AHCI

The installation steps below will guide you in configuring your SATA drive to AHCI mode.

- 1. Enter the BIOS utility and configure the SATA controller to IDE mode.
- 2. Install Windows XP but do not press F6.
- 3. Download relevant RAID/AHCI driver files supported by the motherboard chipset from Intel's website.

Transfer the downloaded driver files to C:\AHCI.



 Open Device Manager and right click on one of the Intel Serial ATA Storage Controllers, then select Update Driver.

> If the controller you selected did not work, try selecting another one.



 In the Hardware Update Wizard dialog box, select "No, not this time" then click Next.



 Select "Install from a list or specific location (Advanced)" and then click Next.



 Select "Don't search. I will choose the driver to install" and then click Next.



8. Click "Have Disk".



 Select C:\AHCI\iaAHCI.inf and then click **Open**.



 Select the appropriate AHCI Controller of your hardware device and then click Next.



11. A warning message appeared because the selected SATA controller did not match your hardware device.

Ignore the warning and click **Yes** to proceed.

12. Click Finish.





- The system's settings have been changed. Windows XP requires that you restart the computer. Click Yes.
- 14. Enter the BIOS utility and modify the SATA controller from IDE to AHCI. By doing so, Windows will work normally with the SATA controller that is in AHCI mode.





Appendix B - Watchdog Sample Code

;Software programming example:

*		
, ;(1) Ent	er Super IO Con	figuration mode
; MOV MOV OUT OUT	DX,2EH AL,87H DX,AL DX,AL	
; ;(2) Co timer)	nfiguration Logi	cal Device 7, register CRF5/CRF6 (WDT Control /WDT
MOV MOV OUT	DX,2EH AL,07H DX,AL	;Ready to Program Logical Device
MOV MOV OUT	DX,2FH AL,07H DX,AL	;Select Logical Device 7
MOV MOV OUT	DX,2EH AL, F6H DX,AL	;Select watchdog timer register
MOV MOV OUT	DX,2FH AL,10H DX,AL	;Set watchdog timer value
MOV MOV OUT	DX,2EH AL, F5H DX,AL	;Select watchdog Control Register
MOV MOV OUT	DX,2FH AL,61H DX,AL	;Set Watchdog Control Value
; ;(1) Exit	extended funct	ion mode
; MOV MOV OUT	DX,2EH AL,AAH DX,AL	

Appendix C - System Error Message

When the BIOS encounters an error that requires the user to correct something, either a beep code will sound or a message will be displayed in a box in the middle of the screen and the message, PRESS F1 TO CONTINUE, CTRL-ALT-ESC or DEL TO ENTER SETUP, will be shown in the information box at the bottom. Enter Setup to correct the error.

Error Messages

One or more of the following messages may be displayed if the BIOS detects an error during the POST. This list indicates the error messages for all Awards BIO-Ses:

CMOS BATTERY HAS FAILED

The CMOS battery is no longer functional. It should be replaced.



Important

Danger of explosion if battery incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the battery manufacturer's instructions.

CMOS CHECKSUM ERROR

Checksum of CMOS is incorrect. This can indicate that CMOS has become corrupt. This error may have been caused by a weak battery. Check the battery and replace if necessary.

DISPLAY SWITCH IS SET INCORRECTLY

The display switch on the motherboard can be set to either monochrome or color. This indicates the switch is set to a different setting than indicated in Setup. Determine which setting is correct, either turn off the system and change the jumper or enter Setup and change the VIDEO selection.

FLOPPY DISK(S) fail (80)

Unable to reset floppy subsystem.

FLOPPY DISK(S) fail (40)

Floppy type mismatch.

Hard Disk(s) fail (80)

HDD reset failed.

Hard Disk(s) fail (40)

HDD controller diagnostics failed.

System Error Message

Hard Disk(s) fail (20)

HDD initialization error.

Hard Disk(s) fail (10)

Unable to recalibrate fixed disk.

Hard Disk(s) fail (08)

Sector Verify failed.

Keyboard is locked out - Unlock the key

The BIOS detects that the keyboard is locked. Keyboard controller is pulled low.

Keyboard error or no keyboard present

Cannot initialize the keyboard. Make sure the keyboard is attached correctly and no keys are being pressed during the boot.

Manufacturing POST loop

System will repeat POST procedure infinitely while the keyboard controller is pull low. This is also used for the M/B burn in test at the factory.

BIOS ROM checksum error - System halted

The checksum of ROM address F0000H-FFFFFH is bad.

Memory test fail

The BIOS reports memory test fail if the memory has error(s).

Troubleshooting Checklist

This chapter of the manual is designed to help you with problems that you may encounter with your personal computer. To efficiently troubleshoot your system, treat each problem individually. This is to ensure an accurate diagnosis of the problem in case a problem has multiple causes.

Some of the most common things to check when you encounter problems while using your system are listed below.

- 1. The power switch of each peripheral device is turned on.
- 2. All cables and power cords are tightly connected.
- 3. The electrical outlet to which your peripheral devices are connected is working. Test the outlet by plugging in a lamp or other electrical device.
- 4. The monitor is turned on.
- 5. The display's brightness and contrast controls are adjusted properly.
- 6. All add-in boards in the expansion slots are seated securely.
- 7. Any add-in board you have installed is designed for your system and is set up correctly.

Monitor/Display

If the display screen remains dark after the system is turned on:

- 1. Make sure that the monitor's power switch is on.
- 2. Check that one end of the monitor's power cord is properly attached to the monitor and the other end is plugged into a working AC outlet. If necessary, try another outlet.
- 3. Check that the video input cable is properly attached to the monitor and the system's display adapter.
- 4. Adjust the brightness of the display by turning the monitor's brightness control knob.

The picture seems to be constantly moving.

- 1. The monitor has lost its vertical sync. Adjust the monitor's vertical sync.
- 2. Move away any objects, such as another monitor or fan, that may be creating a magnetic field around the display.
- 3. Make sure your video card's output frequencies are supported by this monitor.

The screen seems to be constantly wavering.

1. If the monitor is close to another monitor, the adjacent monitor may need to be turned off. Fluorescent lights adjacent to the monitor may also cause screen wavering.

Power Supply

When the computer is turned on, nothing happens.

- 1. Check that one end of the AC power cord is plugged into a live outlet and the other end properly plugged into the back of the system.
- 2. Make sure that the voltage selection switch on the back panel is set for the correct type of voltage you are using.
- 3. The power cord may have a "short" or "open". Inspect the cord and install a new one if necessary.

Floppy Drive

The computer cannot access the floppy drive.

- 1. The floppy diskette may not be formatted. Format the diskette and try again.
- 2. The diskette may be write-protected. Use a diskette that is not write-protected.
- 3. You may be writing to the wrong drive. Check the path statement to make sure you are writing to the targeted drive.
- 4. There is not enough space left on the diskette. Use another diskette with adequate storage space.

Hard Drive

Hard disk failure.

- 1. Make sure the correct drive type for the hard disk drive has been entered in the BIOS.
- 2. If the system is configured with two hard drives, make sure the bootable (first) hard drive is configured as Master and the second hard drive is configured as Slave. The master hard drive must have an active/bootable partition.

Excessively long formatting period.

If your hard drive takes an excessively long period of time to format, it is likely a cable connection problem. However, if your hard drive has a large capacity, it will take a longer time to format.

Serial Port

The serial device (modem, printer) doesn't output anything or is outputting garbled characters.

- 1. Make sure that the serial device's power is turned on and that the device is on-line.
- 2. Verify that the device is plugged into the correct serial port on the rear of the computer.
- 3. Verify that the attached serial device works by attaching it to a serial port that is working and configured correctly. If the serial device does not work, either the cable or the serial device has a problem. If the serial device works, the problem may be due to the onboard I/O or the address setting.
- 4. Make sure the COM settings and I/O address are configured correctly.

Keyboard

Nothing happens when a key on the keyboard was pressed.

- 1. Make sure the keyboard is properly connected.
- 2. Make sure there are no objects resting on the keyboard and that no keys are pressed during the booting process.

System Board

- 1. Make sure the add-in card is seated securely in the expansion slot. If the add-in card is loose, power off the system, re-install the card and power up the system.
- 2. Check the jumper settings to ensure that the jumpers are properly set.
- 3. Verify that all memory modules are seated securely into the memory sockets.
- 4. Make sure the memory modules are in the correct locations.
- 5. If the board fails to function, place the board on a flat surface and seat all socketed components. Gently press each component into the socket.
- 6. If you made changes to the BIOS settings, re-enter setup and load the BIOS defaults.