


Board Layout



Notes:

1. When COM 1 RS232/422/485 is being configured, JP7, JP8, and JP10 must be set in accordance with the same serial mode.
2. When COM 2 RS232/422/485 is being configured, JP11, JP12, and JP13 must be set in accordance with the same serial mode.

Jumper Settings

Clear CMOS Data	JP1
Normal (default)	1-2 On
Clear CMOS Data	2-3 On

RS232/422/485 Select	JP7 (COM 1) JP11 (COM 2)	JP8/JP10 (COM 1) JP12/JP13 (COM 2)
RS232 (default)	1-2 On	1-3, 2-4 On
RS422 Full Duplex	3-4 On	3-5, 4-6 On
RS485	5-6 On	3-5, 4-6 On

RS232/Power Select	JP9 (COM 1), JP14 (COM 2)
RS232 (default)	1-3 (RI-), 2-4 (DCD-) On
RS232 with power	3-5 (+5V), 4-6 (+12V) On

SATA 4/mSATA Signal Select	JP15
SATA 4	1-2 On
mSATA (default)	2-3 On

Mini PCIe/mSATA Signal Select (Q170 only)	JP16
Mini PCIe (default)	1-2 On
mSATA	2-3 On



DFI reserves the right to change the specifications at any time prior to the product's release. This QR may be based on editions that do not resemble your actual products. For more documentation and drivers, please visit the download page at go.dfi.com/KD600-Q170, go.dfi.com/KD600-H110, or via the QR code to the right.



Q170



H110